

ARCONTROL™ BMS

USER MANUAL



Table of Contents

1 Introduction	1
1.1 Hardware Installation	1
1.2 Wiring for Operation	6
1.3 Application Information.....	11
2 System Overview	12
2.1 User Interface	12
2.2 System Splash Window.....	13
2.3 System Menu	13
2.4 System Menu Symbols.....	14
2.5 System Modes	15
2.6 System States.....	15
2.7 State Additional Information or Command	19
2.8 Process 1 (P ₁), 2 (P ₂), 3 (P ₃) and INDEPENDENT (P _I)	20
2.9 Diagnostic Info & Diagnostic Mode	21
3 System Settings.....	24
3.1 Settings Overview	24
3.2 Settings Menu.....	25
3.3 Changing System Settings.....	26
3.4 Setting Options	28
3.5 MODBUS Register Map.....	56
3.6 Data Logs	73
4 System Operation	76
4.1 AUTOMATIC Mode	76
4.2 MANUAL Mode	79
4.3 Alarm & Shutdown States.....	82
4.4 INDEPENDENT Process.....	84
4.5 PID Control Loop.....	85
4.6 Transducer Calibration.....	85
4.7 USB Drive Port Functions.....	86
5 Troubleshooting.....	87
6 Maintenance & Service	87
7 Equipment Ratings.....	88
8 Approvals	88
9 Unit Dimensions	89
9.1 ARControl Enclosure	89
9.2 BMS CID1 Enclosure	90
10 BMS CID1 Enclosure Conduit Seal Placement	91

1 Introduction

Thank you for purchasing the ARControl BMS Module, our most popular process control and ignition package.

This manual will provide you with important information that will help you understand the system, setup the system and how the system operates. Please keep the manual in an accessible location for future reference. At Cimmaron Energy Inc. we are always here to assist you with any service or spare part needs. Contact us at:

Phone: 1-844-746-1676

Website: <https://www.arcontrolbms.com>

1.1 Hardware Installation

The ARControl BMS should be installed according to the directions provided in this manual and always be in compliance with local electrical codes and the specifications of the operating company. This section will cover general instructions regarding safety as well as specific wiring and materials required for the safe and successful operation of the ARControl BMS.

1.1.1 Proper Use of the BMS Module 1870-511

The valve output on the BMS Module is the system's ESD valve and is intended to be installed upstream of all other valves in the ARControl BMS installation. The dual-probe thermocouple input on the BMS Module is intended to be used as the source for the high-temperature cutoff. If the BMS Module 1870-511 is used in a manner not specified by Cimarron Energy, Inc., the protection provided by the equipment may be impaired.

WARNING!

Failure to comply with the following safety warning(s) may result in serious personal injury or death.

- Ensure the power is not connected until the final step of installation.
- Failure of the grounding system integrity can result in personal injury, damage, or failure of operation. The equipment must be grounded in accordance with instructions and devices and wiring connected to the controller must be according to the appropriate electrical code
- Ensure that no personnel nor any objects come into contact with the ignition module, terminals, or damaged coil wiring. The ignition coil can generate 38kV and is considered a hazard.
- If using an external power supply, do not power the ARControl with a supply rated for more than 24VDC.

NOTICE

Failure to comply with the following safety warning(s) may result in damage to the product.

- When installation is complete, ensure that the enclosure is properly sealed and the fasteners are tight. The enclosure will ensure that the internal components are not affected by moisture, ice, or debris.
- Disconnect and remove the battery during transportation or when the ARControl will not be operated for a period of time.

1.1.2 ARControl Installation Guidelines

- A switch or circuit breaker must be included in the installation; it must be suitably located and easily reached. It must be marked as the disconnecting device for the equipment.
- Proper earth grounding per local electrical codes must be utilized in the installation.
- If the ARControl is used in a manner not specified by Cimarron Energy, Inc., the protection provided by the equipment may be impaired.
- If the BMS Module (1870-511) is used in conjunction with the ARControl it must be mounted externally of the ARControl in order for the ARControl to remain regulatory compliant.
- Use the hardware supplied with the ARControl. The hardware kit supplied with the ARControl contains an aluminum pre-drilled mounting bracket, and (4) 3/4-inch bolts and nuts.

- Locate the unit out of traffic and working areas, away from excessive heat, and above areas where water and liquids may accumulate. Visibility of the display will be enhanced if not facing direct sun.
- Measure the wiring distance. The ignition cable is restricted to a length of 25 feet maximum.

1.1.3 ARControl BMS Installation

Follow these steps to install the ARControl BMS (options for DIN mount or CID1, temperature or pressure control):

WARNING: Do not apply power to the system until instructed to do so in step 16. Failure to comply may result in serious personal injury or death.

1. Locate and open the hardware kit.
2. Attach the mounting flanges to the back of the ARControl (1960-155) with the supplied hardware.
3. Drill holes in the bottom of the enclosure to accommodate the cables and conduit to the unit. It is recommended to use a step drill bit to drill the holes.
4. Mount the ARControl via the flanges to a secure location and away from heat sources.
5. Mount provided ignition rod assembly to the pilot or burner assembly.
6. **When installing the BMS Module with included DIN bracket (1960-171) inside of the ARControl:**
 - a. Attach provided cable conduit using provided glands to enclosure and burner chamber.
 - b. Mount the ignition module to the DIN rail on the inside of the enclosure. **WARNING: Mounting ignition module inside enclosure VOIDS the 1960-155 ARControl Class I Division 2 rating.**
 - c. Wire the ignition module to the ARControl's MODULE PORT using the provided wiring harness.
7. **When installing the BMS Module with Class 1 Division 1 enclosure (1960-170) external from the ARControl:**
 - a. Mount the BMS Module enclosure near the burner of the process equipment.
 - b. Attach suitable cable conduit between the ARControl and BMS Module.
 - c. Attach suitable cable conduit between the BMS Module and burner chamber.
 - d. Wire the ignition module to the ARControl's MODULE PORT using suitable 4-conductor cable (Image 1.1.1).
8. Connect the ignition wire to the tab of the BMS Module spark transformer, run it through the conduit and attach it to ignition rod assembly.
9. Attach the free end of the grounding wire (green wire with yellow trace) to the burner's chassis.
10. Install dual-probe thermocouple (148197) in process equipment or combustor stack.
11. Wire dual-probe thermocouple to the BMS Module's thermocouple ports using k-type thermocouple extension wire.
12. If using **Pressure Control** (old SAU functionality), install 0-5 psig transducer (8100-020) in the process gas stream and wire the transducer to the ARControl Transducer Port (Image 1.1.1).
13. Install the ESD valve upstream of the pilot and process valves and wire the ESD valve to the VALVE output of the BMS Module.
14. Install the pilot valve upstream of the pilot and wire the pilot valve to the Pilot Valve output of the ARControl.
15. Install the process 1 valve upstream of the burner and wire the process 1 valve to the Process 1 Valve output of the ARControl.
16. Connect the power source to the power and ground terminal blocks.
17. If using **Pressure Control** (old SAU functionality w/ Barksdale 8100-020), navigate to **SETTING MENU > PROCESS 1** and set the following:
 - **SOURCE** to XDCR
 - **LOGIC** to ↑ ON ↓ OFF
 - **HIGH LEVEL** to 50
 - **LOW LEVEL** to 20




Image 1.1.1 • BMS pressure process control wiring diagram

18. If using the **High-temperature** shutdown feature, navigate to **SETTING MENU > BMS MODULE > TEMP LIMIT** to set the high-temperature shutdown temperature.
19. If using **Temperature Control** (old Torch functionality) (Image 1.2.2), navigate to **SETTING MENU > PROCESS 1** and set:
 - **SOURCE** to **TC BMS**
 - **LOGIC** to **↑ OFF ↓ ON**
 - **HIGH LEVEL** to high process temperature
 - **LOW LEVEL** to low process temperature
20. Navigate to the **START (HOLD OK)** menu entry on the home screen and hold the **OK** key for at least a second. This will start the ignition sequence and process control.




Image 1.1.2 • BMS temperature process control wiring diagram

1.2 Wiring for Operation

This section covers general wiring for most common applications. **Important!** All wiring should be done in accordance with local regulations and within the specifications of the site or equipment owner. If there are questions not answered by this manual or the wiring diagrams, please call Cimarron Energy at 1-844-746-1676 for assistance.

1.2.1 Connecting the Power

The ARControl is designed to operate from either 12 or 24 volt power supplies or batteries. Power supplies should be rated Class II and capable of sourcing a minimum of 2 amps. Batteries should be either 12 or 24 volt and have a minimum 12 Ah (amp-hour) capacity.

1.2.2 Connecting a Solar Panel and Battery (if required)

Solar Charing

The ARControl contains an integrated solar charger. The solar charger is capable of charging a 12 volt 12 Ah SLA (sealed lead acid) battery. A solar panel rated for 12 volt systems with a maximum current output of 2 amps is recommended. Installations that require more charging current than provided by the internal solar charger should utilize a properly sized external solar charger and battery (Image 1.2.1).

Power Pack

The standard ARControl Power Pack (PN: 1960-160) contains a 12 volt 12 Ah SLA battery in a sturdy DIN-mountable bracket and a 5 watt 12 volt solar panel with 9 feet of cable and a mounting bracket. The battery and bracket clips onto the bottom **DIN** rail in the ARControl enclosure. The solar panel can be mounted with a U-bolt to a pole or to any other structure that can accommodate the mounting holes. Be sure to locate the solar panel south facing in an area free from obstruction of the sun throughout the entirety of the day (Image 1.2.2).

Fusing

The ARControl has three user-replaceable fuses. The fuse on the DIN rail mounted terminal block that connects to BATTERY IN on the ARControl utilizes a 5 amp ATC or ATO fuse. The ARControl board is fused at both the POWER PORT and MODULE PORT with 2 amp ceramic fuses (PN: 3181-002). The POWER PORT fuse protects all of the valve outputs and the digital outputs. The MODULE PORT fuse protects the power output to the Ignition Module. There are two spare 2 amp ceramic fuses located in the SPARE FUSES location on the ARControl board.




Image 1.2.1 • Solar panel wiring




Image 1.2.2 • Battery pack wiring

1.2.3 PERMISSIVE (DIN) Input

The **PERMISSIVE** input is used to shutdown the system if it is active. Connect the input to a PLC or some other external switch. By default, the input is active when the circuit is open but this can be changed in the IO settings. It is internally pulled up to 5 VDC. If it is not used it needs to be jumpered (Image 1.2.3).




Image 1.2.3 • PERMISSIVE input wiring

1.2.4 Proof of Closure Input

The **PROOF OF CLOSURE** input is used to check that a valve is closed before the system attempts to ignite.

Important! Failure of this test will transition the system to the **POC FAILURE** state.

Connect the input to a valve's status output, pressure switch, or other device intended to prove the state of the valve. By default, it is active when the circuit is open but this can be changed in the IO settings. The input is internally pulled up to 5 VDC. If this input is not being used it needs to be jumpered (Image 1.2.4).




Image 1.2.4 • Proof of closure input wiring

1.2.5 Pressure Switches PS1 & PS2

The Pressure Switch inputs, PS1 & PS2, are generic digital inputs. They can be used as sources for the Shutdowns.

By default, they are active when the circuit is open but this can be changed in the IO settings. They are internally pulled up to 5 VDC (Image 1.2.5).




Image 1.2.5 • Pressure switch input wiring

1.2.6 Transducer Port Input

The Transducer Port input accepts multiple different transducer types. The Transducer Port input can be used as a source for the Processes and Shutdowns (Image 1.2.6).




Image 1.2.6 • Transducer port input wiring

1.2.7 Thermocouple Inputs 1 & 2

Thermocouple inputs 1 & 2 accept k-type thermocouples. They can be used as sources for the Processes and Shutdowns. If they are not used they need to be jumpered (Image 1.2.7).




Image 1.2.7 • Thermocouple (TC1 & TC2) input wiring

1.2.8 Modbus RS-485

To use Modbus communication, use the RS-485 PORT on the board, attaching the A+ and B- wiring as well as the GND to the external PLC or communication device. Notifications of alarms can also be retrieved via Modbus (Image 1.2.8).




Image 1.2.8 • Modbus RS-485 wiring

1.2.9 Pilot Status Output

The Pilot Status output indicates if the system is detecting flame at the pilot. This output can drive an indicator light or interface with an external PLC. The output voltage is the same as **BATTERY-IN**. The combined current output of Pilot Status and all of the valves is 2 A MAX (Image 1.2.9).




Image 1.2.9 • Pilot status output wiring

1.2.10 Valves Pilot, Process 1, Process 2, Process 3, and Independent Process

The valve outputs are intended to drive solenoid valves. They have user-adjustable peak-and-hold capability. The output voltage is the same as **BATTERY-IN**. The combined current output of Pilot Status and all of the valves is 2 A MAX (Image 1.2.10).




Image 1.2.10 • Valve pilot, process 1, 2, 3 and Independent wiring

1.3 Application Information

1.3.1 Alarm Output

The Alarm output indicates if the system is in an abnormal state such as a Shutdown or **PILOT FAILURE**. The output behaves as a switch. By default, it is closed when there is no alarm condition but this can be changed in the IO settings. External alarm circuitry should be limited to 50mA (Image 1.3.1).





Image 1.3.1 • Alarm output inactive



Alarm output inactive/closed switch circuit diagram

2 System Overview

2.1 User Interface

The system user interface (Image 2.1.1) consists of a text display and seven keys (Table 2.1.1) that are used for menu navigation, selecting options on menu items and entering or exiting menus.

The text display provides information regarding menus, submenus, system modes, selectable options, current mode operation states and alarms. The text display features automatic shutoff after 60 seconds without user interaction through the keypad. The automatic shutoff feature helps save power which is especially important in remote installations that are solar powered.

Pressing any key will wake up the text display and bring it to the top of the Main menu. If the **STOP** key is pressed while the text display is off, it will both send the unit in to the **STOPPED** state and wake up the text display. Additionally, if the system enters into any of the alarm states this will also wake up the text display and it will bring the alarm state screen.




Image 2.1.1 • System user interface

KEY	USE	DESCRIPTION
Up	Use to scroll up menu items	
Down	Use to scroll down menu items	
Left	Use to toggle through selectable options	Selectable options are shown between angle brackets < >
Right	Use to toggle through selectable options	Selectable options are shown between angle brackets < >
OK	Use to enter a submenu and select or enter menu item choice	The OK key allows the entering of menu item actions and choices, and to and accept or deny system confirmation screens.
BACK	Use to exit a selected submenu or cancel / deny prompts	
STOP	Use to put the system in STOP state	The STOP key interrupts any current operation and sends the system to the STOPPED state.

Table 2.1.1 • User interface keys

2.2 System Splash Window

When the system powers up the System Splash window (Image 2.2.1) will appear for 2 seconds. The splash window contains the product's name and the system's firmware identification version number and revision level.



Image 2.2.1 • System splash window

2.3 System Menu

The System Menu displays the current system state, additional information about the system state, the current values of the processes, and the current operating mode. It also provides access to the Process Quick Set-up menu, Diagnostics Information, Settings, and Service Info menus (Table 2.3.1).

The additional state information consists of state countdowns, state durations, and commands to interact with the system. The information that is displayed depends on which state the system is in. The System Menu is shown in the text display (Image 2.3.1) and displays the following:

- Current system state
- Additional information about the current system state and prompts for actionable menu items
- Current value of Process 1 (select to access the process 1 quick set-up menu)
- Current value of Process 2 (select to access the process 2 quick set-up menu)
- Current value of Process 3 (select to access the process 3 quick set-up menu)
- Current value of Process Independent (select to access the process Independent quick set-up menu)
- Current mode (select to toggle between **AUTOMATIC** and **MANUAL** modes)
- Diagnostics information (select to navigate to diagnostic information and actionable items)
- Settings Menu (select to navigate to setting submenus)
- Service Info (select to navigate to service information)

MENU ITEM	FUNCTION
CURRENT STATE	Reports the system current state of operation. The reported state varies as a function of the current system mode.
STATE ADDITIONAL INFORMATION OR COMMAND	Reports additional information about the current state of the system. This additional information include countdown, duration of the system in the current state and action the user can take at the current state.
PROCESS 1, 2, 3 AND INDEPENDENT	Display the current process variable value and units for a process. Additionally, this entry navigates to the process' quick set menu where high and low level can be set within allowable ranges.
MODE	Reports the systems current mode of operation (AUTOMATIC or MANUAL)
DIAGNOSTICS INFO	Navigates into a the diagnostics info menu which displays the state of each input and output. The Diagnostic Mode menu is the last item in the Diagnostic Info Menu, it allows the user to toggle the outputs in order to test the system.
SETTINGS MENU	Navigates into settings menu
SERVICE INFO	Navigates service and diagnosis information menu

Table 2.3.1 • System menu items

Current state	→	S	T	A	T	E	=	[C	U	R	R			S	T	A	T	E]		
Additional Info		[S	T	A	T	E		A	D	D	T	L		I	N	F	O]		
Current value:		≡	P ₁	=				[C	U	R	R			V	A	L	U	E]	↵	
process 1																						
		≡	P ₂	=				[C	U	R	R			V	A	L	U	E]	↵	Current value: process 2
Current value:		≡	P ₃	=				[C	U	R	R			V	A	L	U	E]	↵	
process 3																						
		≡	P _I	=				[C	U	R	R			V	A	L	U	E]	↵	Current value: process Independent
Current mode		M	O	D	E	=		[C	U	R	R	E	N	T		M	O	D	E]	
		≡	D	I	A	G	N	O	S	T	I	C	S		I	N	F	O		↵	Diagnostics information	
Settings submenu		≡	S	E	T	T	I	N	G	S		M	E	N	U					↵		
Service info submenu		≡	S	E	R	V	I	C	E		I	N	F	O						↵		

Image 2.3.1 • System menu

The following is an example of using the System Menu:

Example: Changing the operation mode from **AUTOMATIC** to **MANUAL** mode (Image 2.3.2).

1. Use the **UP** or **DOWN** key and select **MODE**.
2. Press the **OK** key.
3. Using **LEFT** and **RIGHT** key scroll to the **MANUAL** menu entry.
4. Press the **OK** key. The system will now be in the **MANUAL** mode. **Note:** The current state of the mode is shown in the **STATE** row.




Image 2.3.2 • Change operation mode

2.4 System Menu Symbols

The symbols shown in the System Menu signify the following:

- Indicates current menu selection
- ≡ Indicates a submenu
- ↵ Indicates an actionable menu item
- < > Indicates a user selectable option
- [] Indicates dynamic text related to user selection
- X X X X . X Indicates placeholders for numerical values

2.5 System Modes

The system has two operation modes, **AUTOMATIC** and **MANUAL**, to choose from. In **AUTOMATIC** mode (Image 2.5.1) ignition is initiated by the user. Once the pilot is lit, the system will automatically start controlling the process and attempt to relight the pilot if flame is lost. **ON DEMAND** mode is also available which only lights the pilot when flame is required by a process. **AUTOMATIC** mode is the default system operation mode.

→	M	O	D	E	=					A	U	T	O	M	A	T	I	C
	≡	D	I	A	G	N	O	S	T	I	C	S		I	N	F	O	↵

Image 2.5.1 • AUTOMATIC mode

In **MANUAL** mode (Image 2.5.2) the duration of ignition is manually controlled by the user. Once the pilot is lit, the user must initiate the process control. The system will not attempt to automatically relight if flame is lost. **ON DEMAND** mode is not available in **MANUAL** mode operation.

→	M	O	D	E	=									M	A	N	U	A	L
	≡	D	I	A	G	N	O	S	T	I	C	S		I	N	F	O		↵

Image 2.5.2 • MANUAL mode

2.6 System States

Each system mode has multiple operation states (Table 2.6.1 & 2.6.2) and alarm states (Table 2.6.3). The current operation state is displayed on the System Menu (Image 2.6.1). Upon power-up in **AUTOMATIC** mode, the system initializes in the **STOPPED** state.

Note: An **INDEPENDENT** process runs independently of all other system states including alarm and shutdown states. The **INDEPENDENT** process is only *inactive* in **DIAGNOSTIC** mode.

Default state		S	T	A	T	E	=						S	T	O	P	P	E	D		
		[S	T	A	T	E		A	D	D	T	L		I	N	F	O]	
		≡	P ₁	=				[C	U	R	R			V	A	L	U	E]	↵
		≡	P ₂	=				[C	U	R	R			V	A	L	U	E]	↵
		≡	P ₃	=				[C	U	R	R			V	A	L	U	E]	↵
	≡	P _I	=				[C	U	R	R			V	A	L	U	E]	↵	
Default mode	→	M	O	D	E	=					A	U	T	O	M	A	T	I	C		
		≡	D	I	A	G	N	O	S	T	I	C	S		I	N	F	O		↵	
		≡	S	E	T	T	I	N	G	S			M	E	N	U				↵	
		≡	S	E	R	V	I	C	E			I	N	F	O					↵	

Image 2.6.1 • Default operation mode and state

AUTOMATIC MODE OPERATIONAL STATES		
STATE	DISPLAY	DESCRIPTION
STOPPED	STOPPED	In the STOPPED state, the system closes all valves and activates the ALARM output. If ON DEMAND is disabled and the user initiates the system by pressing and holding the OK button for a second or more, the system will transition to the START-UP state. If ON DEMAND is enabled and the user initiates the system by pressing and holding the OK button for a second or more, the system will transition to the IDLE state.
START-UP	START-UP	In the START-UP state the system checks the input PS3 (PROOF OF CLOSURE) . If the input is active then the system transitions to the POC FAILURE state, if it is inactive the system transitions to the PRE-PURGE state.
PRE-PURGE	PRE-PURGE	In the PRE-PURGE state, the system delays for the PREPURGE TIME before transitioning to the IGNITING state and the IGNITION RETRY(s) are reset. The PRE-PURGE state is intended to provide time for the system to purge itself of unignited gas.
IGNITE	IGNITE	In the IGNITE state, the system begins ignition, opens the ESD and Pilot valves, and then continues to ignite for the IGNITION TIME or until flame is detected. If flame is detected the system will transition to the ESTABLISHING PILOT state. If the ignition time expires before flame is detected, then the system will transition to the PURGE state.
PURGE	PURGE	In the PURGE state, the system closes all valves. If there are IGNITION RETRY(s) remaining, the system delays for the PURGE TIME before transitioning to the IGNITE state. If there are no IGNITION RETRY(s) remaining, the system transitions to the WAIT state. The PURGE state is intended to provide time for the system to purge itself of unignited gas.
WAIT	WAIT	In the WAIT state, the system closes all valves. If there are WAIT RETRY(s) remaining, the system delays for the WAIT TIME before transitioning to the PRE-PURGE state. If there are no WAIT RETRY(s) remaining, the system transitions to the PILOT FAILURE state.
ESTABLISH PILOT	EST PILOT	In the EST PILOT state, the system checks for the continuous presence of flame for the PILOT EST TIME . If the flame is continuously present for the PILOT EST TIME , the system transitions to the PILOT ON state. If flame is lost during the PILOT EST TIME , the system resets the IGNITION RETRY(s) and transitions to the IGNITION state.
PILOT ON	PILOT ON	In the PILOT ON state, the system will wait to transition to an ACTIVE state until one of the processes becomes active. If flame is lost in the PILOT ON state, the system resets the IGNITION RETRY(s) and transitions to the IGNITION state.
IDLE	IDLE	In the IDLE state, the system closes all valves and waits indefinitely until a process becomes active. If a process becomes active, the system will transition to the START-UP state.
ACTIVE 1	ACTIVE PRCS 1	In any of the ACTIVE states, the system continually checks the state of all processes. If a process becomes active, the system will open the process' valve and update the state name accordingly. If any process becomes inactive, the system will close that process' valve and update the state name accordingly. If all processes become inactive, the system will transition back to the PILOT ON state if ON DEMAND is disabled or to the IDLE state if ON DEMAND is enabled.
ACTIVE 2	ACTIVE PRCS 2	
ACTIVE 3	ACTIVE PRCS 3	
ACTIVE 1+2	ACTIVE PRCS 1,2	
ACTIVE 1+3	ACTIVE PRCS 1,3	
ACTIVE 2+3	ACTIVE PRCS 2,3	
ACTIVE 1+2+3	ACTIVE PRCS ALL	

Table 2.6.1 • AUTOMATIC mode operational states

MANUAL MODE OPERATION MODES		
STATE	DISPLAY	DESCRIPTION
STOPPED	STOPPED	In the STOPPED state, the system closes all valves and activates the ALARM output. If the user initiates the system by pressing and holding the OK and → keys for a second or more, the system will transition to the START-UP state.
START-UP	START-UP	In the START-UP state the system checks the input PS3 (PROOF OF CLOSURE). If the input is active then the system transitions to the POC FAILURE state. If the input is inactive the user is still holding OK and → keys, the system transitions to the PRE-PURGE state.
PRE-PURGE	PRE-PURGE	In the PRE-PURGE state, if the user is still holding the OK and → keys, the system delays for the PREPURGE TIME before transitioning to the IGNITING state. The PRE-PURGE state is intended to provide time for the system to purge itself of unignited gas.
IGNITE	IGNITE	In the IGNITE state, if the user is still holding the OK and → keys, the system begins ignition, opens the ESD and Pilot valves, and then continues to ignite for up to 60 seconds or until flame is detected. If flame is detected the system will transition to the IDLE state. If the ignition time expires before flame is detected or the user releases the OK and → keys, then the system will transition to the STOPPED state.
PILOT ON	PILOT ON	In the PILOT ON state, the system will wait to transition to an ACTIVE state until one of the processes becomes active. If pilot flame is lost, the system will transition to the STOPPED state
IDLE	IDLE	In the IDLE state, the system waits for the user to press the OK key in order to begin the processes. If the user presses the OK key, the system will transition to the PILOT ON state.
ACTIVE 1	ACTIVE PRCS 1	In any of the ACTIVE states, the system continually checks the state of all processes. If a process becomes active, the system will open the process' valve and update the state name accordingly. If any process becomes inactive, the system will close that process' valve and update the state name accordingly. If all processes become inactive, the system will transition back to the PILOT ON state. If pilot flame is lost, the system will transition to the STOPPED state.
ACTIVE 2	ACTIVE PRCS 2	
ACTIVE 3	ACTIVE PRCS 3	
ACTIVE 1+2	ACTIVE PRCS 1,2	
ACTIVE 1+3	ACTIVE PRCS 1,3	
ACTIVE 2+3	ACTIVE PRCS 2,3	
ACTIVE 1+2+3	ACTIVE PRCS ALL	

Table 2.6.2 • MANUAL mode operational states

2.6.1 Shutdown States

Shutdowns stop the system if the system is in an **ACTIVE**, **PILOT ON**, or **IDLE** state and the user-defined conditions of the shutdown are met (Table 2.6.3). These allow for the system to be shut down for conditions such as over-temperature, over-pressure, high- or low-level limits, digital inputs, and more.

SHUTDOWN STATE	DESCRIPTION
SHUTDOWN 1	The system will enter a SHUTDOWN state if any of the SHUTDOWN(s) conditions are met while the system is in any of the ACTIVE , PILOT ON , or IDLE states. In the SHUTDOWN state, the system closes all valves, except for the INDEPENDENT process, and activates the ALARM output. The system will remain in the ALARM state until the user clears the alarm. The system will transition to the STOPPED state once the alarm is cleared.
SHUTDOWN 2	
SHUTDOWN 3	

Table 2.6.3 • Shutdown states

2.6.2 Alarm States

The system monitors various parameters for undesirable conditions, some of which are configurable, and will enter an **ALARM** state if those conditions are met. This is to ensure proper operation of the system and control of the processes.

Alarms and Shutdowns will stop the system processes if certain conditions are met. Alarms stop the system, regardless of what state it is in, if the permissive is active, battery voltage is low, failure to light the pilot, proof of valve closure was not proved, or the high temperature limit reached. Whereas shutdowns stop the system if the system is in an **ACTIVE**, **PILOT ON**, or **IDLE** state and the user-defined conditions of the shutdown are met.

In all alarm states the system closes all valves, except for the Independent process, and activates the **ALARM** output. The system will transition to the **STOPPED** state once all alarms are cleared.

A	L	A	R	M	!		A	L	A	R	M	!		A	L	A	R	M	!
A	L	A	R	M	:				L	O	W		B	A	T	T	E	R	Y
D	I	N	:	[S	T	A	T	E]		B	V	=	1	1	.	4	V
	P	R	E	S	S		O	K		T	O		C	L	E	A	R		

Image 2.6.2 · Example of alarm state

ALARM STATE	DESCRIPTION
PILOT FAILURE	The system will enter the PILOT FAILURE alarm state if it has not been able to establish pilot flame and there is no IGNITION RETRY(s) and WAIT RETRY(s) remaining. The system will remain in this state indefinitely or until the user clears the alarm.
PROOF OF CLOSURE (POC) FAILURE	The system will enter the POC FAILURE alarm state if the PS3 input (PROOF OF CLOSURE) is active during the START-UP state. The system will remain in this state indefinitely or until the user clears the alarm.
LOW BATTERY	The system will enter the LOW BATTERY alarm state if the voltage detected at the BATTERY-IN input drops to or below the BATTERY LVD → LOW LEVEL . The system will remain in this state indefinitely or until the voltage detected at the BATTERY-IN input is at or above the BATTERY LVD → OK LEVEL and the user clears the alarm.
PERMISSIVE OPEN	The system continually monitors the (DIN) PERMISSIVE input. The system will enter the PERMISSIVE OPEN alarm state if the permissive input becomes active. The system will remain in this state indefinitely or until the permissive input is no longer active and the user clears the alarm.
BMS FAULT	The BMS Module continually runs self-test to ensure its proper operation. It continually reports the status of these test to the ARControl. The system will enter a BMS FAULT alarm state if the BMS Module has detected a lockout condition or if the system stops receiving communication from the BMS Module. The system will remain in this state until the BMS Module lockout condition is remedied and the user clears the alarm.

Table 2.6.4 · Alarm states

2.7 State Additional Information or Command

STATE ADDTL INFO (Image 2.7.1) reports additional information about the current state of the system for each operation mode (Table 2.7.1 & 2.7.2). This additional information includes countdown, duration of the system in the current state and actions the user can take at the current state.




Image 2.7.1 • State additional information or command

AUTOMATIC MODE		
OPERATION STATE	SYSTEM MENU DISPLAY	DESCRIPTION
STOPPED	START (HOLD OK) ↵	Actionable menu item: START (HOLD OK)
START-UP	CHECKING SYSTEM...	Indicates system is checking the input PS3 (PROOF OF CLOSURE)
PRE-PURGE	mm:ss	Displays pre-purge time before transitioning to the IGNITE state (minutes : seconds)
IGNITE	mm:ss	Displays the remaining ignition time (minutes : seconds)
PURGE	IGN RETRY=XX mm:ss	Displays the remaining purge time and number of ignition retries remaining (minutes : seconds)
WAIT	WAIT RETRY=XX mm:ss	Displays the wait time if there are WAIT retry(s) remaining (minutes : seconds)
EST PILOT	mm:ss	Displays the remaining time that the system will check for the continuous presence of flame (minutes : seconds)
PILOT ON	DDDDDDDDDD:hh:mm:ss	Displays elapsed time the Pilot is on (days: hour: minutes : seconds)
IDLE	DDDDDDDDDD:hh:mm:ss	Displays elapsed time the system is idle (days: hour: minutes : seconds)
ACTIVE PRCS 1	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 (days: hour: minutes : seconds)
ACTIVE PRCS 2	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 2 (days: hour: minutes : seconds)
ACTIVE PRCS 3	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 3 (days: hour: minutes : seconds)
ACTIVE PRCS 1,2	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 & 2 (days: hour: minutes : seconds)
ACTIVE PRCS 1,3	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 & 3 (days: hour: minutes : seconds)
ACTIVE PRCS 2,3	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 2 & 3 (days: hour: minutes : seconds)
ACTIVE PRCS ALL	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 & 2 & 3 (days: hour: minutes : seconds)

Table 2.7.1 • State additional information - AUTOMATIC mode

MANUAL MODE		
OPERATION STATE	SYSTEM MENU DISPLAY	DESCRIPTION
STOPPED	HOLD OK+→ 2 STRT ↵	Actionable menu item: Hold the OK+→ key for at least a second to start ignition
START-UP	CHECKING SYSTEM...	Indicates system is checking the input PS3 (PROOF OF CLOSURE)
PRE-PURGE	mm:ss	Displays pre-purge time before transitioning to the IGNITE state (minutes : seconds)
IGNITE	mm:ss	Displays the remaining ignition time (minutes : seconds)
PILOT ON	DDDDDDDDDD:hh:mm:ss	Displays elapsed time the Pilot is on (days: hour: minutes : seconds)
IDLE	DDDDDDDDDD:hh:mm:ss	Displays elapsed time the system is idle (days: hour: minutes : seconds)
ACTIVE PRCS 1	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 (days: hour: minutes : seconds)
ACTIVE PRCS 2	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 2 (days: hour: minutes : seconds)
ACTIVE PRCS 3	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 3 (days: hour: minutes : seconds)
ACTIVE PRCS 1,2	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 & 2 (days: hour: minutes : seconds)
ACTIVE PRCS 1,3	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 & 3 (days: hour: minutes : seconds)
ACTIVE PRCS 2,3	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 2 & 3 (days: hour: minutes : seconds)
ACTIVE PRCS ALL	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 & 2 & 3 (days: hour: minutes : seconds)

Table 2.7.2 • State additional information - MANUAL mode

2.8 Process 1 (P₁), 2 (P₂), 3 (P₃) and INDEPENDENT (P_I)

There are four process menus (Image 2.8.1), one for each process: 1 (P₁), 2 (P₂), 3 (P₃), and the **INDEPENDENT (P_I)** process. Each process has the settings: **SOURCE**, **LOGIC**, **HIGH LEVEL**, **LOW LEVEL**, **CEILING**, and **FLOOR** (Table 2.8.1).

→	≡	P ₁	=		[C	U	R	R			V	A	L	U	E]	↵
	≡	P ₂	=		[C	U	R	R			V	A	L	U	E]	↵
	≡	P ₃	=		[C	U	R	R			V	A	L	U	E]	↵
	≡	P _I	=		[C	U	R	R			V	A	L	U	E]	↵

Image 2.8.1 • Process 1 (P₁), 2 (P₂), 3 (P₃) and INDEPENDENT (P_I)

STATE	DESCRIPTION
SOURCE	Selects which inputs is used as the process current value or process variable.
LOGIC	Selects the logic applied to the high and low levels and the output of the process.
HIGH LEVEL	Selects the process upper threshold value.
LOW LEVEL	Selects the shutdown lower threshold value.
CEILING	Sets the limit of how high the process HIGH LEVEL can be set from the process quick set menu.
FLOOR	Sets the limit of how low the process LOW LEVEL can be set from the process quick set menu.

Table 2.8.1 • Process 1 (P₁), 2 (P₂), 3 (P₃) and INDEPENDENT (P_I) settings

Process Quick Set Menu

The **PROCESS QUICK SET** menus allow the user to set the **HIGH LEVEL** and **LOW LEVEL** of the selected process. The **PROCESS QUICK SET** menu will appear after selecting a process on the system menu (Image 2.8.2).




Image 2.8.2 • Select a process

The second line on the **PROCESS QUICK SET** menu displays the set value for the process high level ceiling “**CL=**” and the low-level floor value “**FL=**” so that the user is aware of the allowable limits. Line 3 and 4 allows the user to enter the **HIGH LEVEL** and **LOW LEVEL** settings for the process.



Image 2.8.3 • Set the process HIGH and LOW levels

Note: The user can set the **HIGH LEVEL** and **LOW LEVEL** as follows (Image 2.8.4):

- The **HIGH LEVEL** can be set up to the **CEILING** value to just above the **LOW LEVEL** (**CL >= HIGH LEVEL > LOW LEVEL**).
- The **LOW LEVEL** can be set down to the **FLOOR** value to just below the **HIGH LEVEL** (**FL <= LOW LEVEL < HIGH LEVEL**).




Image 2.8.4 • Process HIGH and LOW LEVEL settings

2.9 Diagnostic Info & Diagnostic Mode

The **DIAGNOSTIC INFO** menu (Image 2.9.1) allows the user to view the real time status of the inputs and outputs (Table 2.9.1). This allows the user to compare the system’s internal state to the actual state of the system and troubleshoot quickly.




Image 2.9.1 • DIAGNOSTIC INFO

MENU ITEM	DESCRIPTION
BATTERY	Shows the current voltage reading across the BATTERY-IN and GND terminals
SOLAR	Shows the current voltage reading across the SOLAR and GND terminals
TC 1	Shows the current temperature reading from thermocouple 1
TC 2	Shows the current temperature reading from thermocouple 2
TC BMS	Shows the current temperature reading from the BMS Module's dual-element thermocouple input
XDCR	Shows the current reading of the transducer input
PILOT VLV	Shows the current state of the PILOT VALVE output
PRCS 1 VLV	Shows the current state of the PROCESS 1 VALVE output
PRCS 2 VLV	Shows the current state of the PROCESS 2 VALVE output
PRCS 3 VLV	Shows the current state of the PROCESS 3 VALVE output
PS1	Shows the current state of the PS1 input
PS2	Shows the current state of the PS2 input
PROOF CLOS	Shows the current state of the PROOF OF CLOSURE input
PERMISSIVE	Shows the current state of the PERMISSIVE input
PILOT STAT	Shows the current state of the PILOT STATUS output
I PRCS VLV	Shows the current state of the INDEPENDENT PROCESS VALVE output
ALARM	Shows the current state of the ALARM output
FLAME SENSE GRADE	Shows a weighted perceived "strength" of the flame sensing feedback loop. This is only intended to be a tool in determining potential weak connection in the flame sense circuit chassis return.
AMB TEMP	Shows the current ambient temperature as sensed by the ARControl main board
DIAGNOSTIC MODE	Sets the system to the diagnostic state which allows the user to manually toggle the outputs

Table 2.9.1 • DIAGNOSTIC INFO menu items

Entering the **DIAGNOSTIC MODE** menu (Image 2.9.2) from the **DIAGNOSTIC INFO** menu configures the system so that the outputs are all set to the **INACTIVE** state.




Image 2.9.2 • Select DIAGNOSTIC MODE

From the **DIAGNOSTIC MODE** menu the user can toggle the state of the outputs from **INACTIVE** to **ACTIVE** and vice versa. The following is a description of the **DIAGNOSTIC MODE** menu items (Table 2.9.2).

MENU ITEM	DESCRIPTION
EXIT DIAGNOSTIC	Exits the diagnostic mode and returns the system to the STOPPED state
IGNITE	Pressing OK activates the ignition circuitry of the system. Pressing OK again stops ignition.
CALL FOR HEAT	Pressing OK starts an ignition sequence with proper timing and opening the BMS Module's ESD valve output
PILOT VLV	Pressing OK toggles the state of the PILOT VALVE output
PRC 1 VLV	Pressing OK toggles the state of the PROCESS 1 VALVE output
PRC 2 VLV	Pressing OK toggles the state of the PROCESS 2 VALVE output
PRC 3 VLV	Pressing OK toggles the state of the PROCESS 3 VALVE output
PLT STAT	Pressing OK toggles the state of the PILOT STATUS output
I PRC VLV	Pressing OK toggles the state of the INDEPENDENT PROCESS VALVE output
ALARM	Pressing OK toggles the state of the ALARM output
FLAME SENSE GRADE	Shows a weighted perceived "strength" of the flame sensing feedback loop. This is only intended to be a tool in determining potential weak connection in the flame sense circuit chassis return.
FLAME	Shows a YES/NO determination if the system has detected the flame
TC 1	Shows the current temperature reading from THERMOCOUPLE 1
TC 2	Shows the current temperature reading from THERMOCOUPLE 2
TC BMS	Shows the current temperature reading from the BMS Module's dual-element thermocouple input
XDCR	Shows the current reading of the TRANSDUCER input
PS1	Shows the current state of the PS1
PS2	Shows the current state of the PS2
PROOF CLS	Shows the current state of the PROOF OF CLOSURE input
PERMISSIVE	Shows the current state of the PERMISSIVE input

Table 2.9.2 · DIAGNOSTIC MODE menu items

3 System Settings

3.1 Settings Overview

The **SETTINGS MENU** (Image 3.1.1) allows the user to adjust the system settings (Table 3.1.1) and perform system level actions such as a factory reset of the system settings or clearing the data logs.




Image 3.1.1 • SETTINGS MENU

MENU ITEM	DESCRIPTION
BMS MODULE	The BMS MODULE menu allows the user to adjust the timing parameters for the ignition sequence, whether the system is in AUTOMATIC or MANUAL mode, if PILOT ON DEMAND is enabled or disabled, and set the TEMP LIMIT for the high temperature lockout.
PROCESS 1	There are four PROCESS menus, one for each process: 1, 2, 3, and INDEPENDENT . Each process has the settings: SOURCE , LOGIC , HIGH LEVEL , LOW LEVEL , CEILING and FLOOR .
PROCESS 2	
PROCESS 3	
PROCESS IND	
PID	The PID menu has six settings: SOURCE , SETPOINT , P VALUE , I VALUE , D VALUE , and DEADBAND VALUE . The control output of the PID controller is the optional ARControl 4-20 mA module.
SHUTDOWN 1	There are three SHUTDOWN menus, one for each shutdown: 1, 2, and 3. Each shutdown has the settings: SOURCE , LOGIC , HIGH LEVEL , and LOW LEVEL .
SHUTDOWN 2	
SHUTDOWN 3	
VALVE TIMING	The four valve outputs (Main Valve, Pilot Valve, Valve A, Valve B) have three settings each: DEADTIME , DELAY , and DUTY .
BATTERY LVD	The BATTERY LVD menu has two settings: OK LEVEL and LOW LEVEL . When the battery voltage transitions from above to at or below the LOW LEVEL setting the system enters the LOW BATTERY state in which all processes except for the Independent process is stopped. The processes can only be started again once the battery voltage transitions from below to at or above the OK LEVEL setting.
MODBUS RS485	The MODBUS RS485 menu has three settings: ADDRESS , BAUDRATE , and WORD ORDER . These settings allow the system to communicate with most PLCs and other industrial communication equipment.
DATALOG	The DATALOG menu has three settings: CONTRACT HOUR , DOWNLOAD MODE , and LOG FREQUENCY . These settings allow the customization of log frequency to meet customer or regulatory requirements.
CALIB XDCR	The CALIB XDCR menu has four settings: SPAN , ZERO , UNITS , and DECIMAL PLACE for transducer calibration. These settings allow the system to accurately read different transducer topologies.
CALIB TC	The CALIB TC menu has three settings: OFFSET TC1 , OFFSET TC2 , and UNITS for thermocouple calibration. These settings allow for correction of offset from the thermocouples. The UNITS selection allows flexibility throughout international regions.

Table 3.1.1 • SETTINGS MENU system settings

MENU ITEM	DESCRIPTION
IO SETTINGS	The IO SETTINGS menu has six settings: ALARM mode, XDCR TYPE (transducer type), DIN mode, PS1 mode, PS2 mode, and PS3 mode. The ALARM , PERMSVE , PS1 , PS2 , and PoC MODE selects if the input is normally open or normally closed when inactive. The system is able to interface with numerous transducer types, offering great system flexibility, which are selectable under XDCR TYPE .
USER PASSCODE	The USER PASSCODE menu is used to sets the passcode to be used to access Settings and Diagnostics Menus. It is also used to enable or disable the use of a passcode to restrict access to Settings and Diagnostics Menus.
DISPLAY	The DISPLAY menu is used to set the amount of time that the display will remain on after the last menu interaction.
SET DATE & TIME	The SET DATE & TIME menu is used to set the date (month, day and year) and the time (hour, minute, AM or PM) .
CLEAR DATA LOGS	The CLEAR DATA LOGS menu has used to clear the data logs.
SET SITE NAME	The SET SITE NAME menu is used to set the name of the site.
FACTORY RESET	The FACTORY DEFAULT menu is used to set all settings to their factory defaults.

Table 3.1.1 • SETTINGS MENU system settings (continued)

3.2 Settings Menu

To change the settings you must enter the **Settings Menu**. Follow these steps to enter the **Settings Menu**:

1. Use the **UP** or **DOWN** key and select **SETTINGS MENU** (Image 3.2.1).
2. Press the **OK** key.




Image 3.2.1 • Select **SETTINGS MENU**

Once in the **Settings Menu** the system settings will be displayed (Image 3.2.2). **Note:** The text display only shows four rows at a time.

→	≡	B	M	S		M	O	D	U	L	E						↵
	≡	P	R	O	C	E	S	S	1								↵
	≡	P	R	O	C	E	S	S	2								↵
	≡	P	R	O	C	E	S	S	3								↵
	≡	P	R	O	C	E	S	S	I	N	D						↵
	≡	P	I	D													↵
	≡	S	H	U	T	D	O	W	N	1							↵
	≡	S	H	U	T	D	O	W	N	2							↵
	≡	S	H	U	T	D	O	W	N	3							↵
	≡	V	A	L	U	E		T	I	M	I	N	G				↵
	≡	B	A	T	T	E	R	Y		L	V	D					↵
	≡	M	O	D	B	U	S		R	S	4	8	5				↵
	≡	D	A	T	A	L	O	G									↵
	≡	C	A	L	I	B		X	D	C	R						↵
	≡	C	A	L	I	B		T	C								↵
	≡	I	O		S	E	T	T	I	N	G	S					↵
	≡	U	S	E	R		P	A	S	S	C	O	D	E			↵
	≡	D	I	S	P	L	A	Y									↵
		S	E	T		D	A	T	E		&		T	I	M	E	↵
		C	L	E	A	R		D	A	T	A		L	O	G	S	↵
		S	E	T		S	I	T	E		N	A	M	E			↵
		F	A	C	T	O	R	Y		R	E	S	E	T			↵

Image 3.2.2 • System settings menu

3.3 Changing System Settings

Follow these steps after selecting the desired system setting to change:

1. Using the **UP** and **DOWN** key to move the arrow on the left hand side of the menu and navigate to desired setting (i.e.: **BMS MODULE**) (Image 3.3.1).
2. Press the **OK** key.





Image 3.3.1 • Select system setting

- Using the **UP** and **DOWN** key to move the arrow on the left hand side of the menu and navigate to desired subsetting (i.e.: **MODE**) (Image 3.3.2).
- Using **LEFT** and **RIGHT** key scroll through the possible options for the setting. For example, change the **MODE** to **MANUAL** (Image 3.3.2)
- If needed, repeat steps 3 and 4 for the remaining settings.



	C	O	M	M	I	T		S	E	T	T	I	N	G	S				⏪
→	M	O	D	E	=	<							M	A	N	U	A	L	>
	P	R	E	P	U	R	G	E		T	I	M	E	=	<	0	0	5	>
	I	G	N	I	T	I	O	N		T	I	M	E		=	<	3	0	>

Use the Up or Down key and move arrow to the desired subsetting

Use the Left or Right key and toggle to the desired setting

Image 3.3.2 • Select subsetting

- When satisfied with the setting changes use the **UP** and **DOWN** key and navigate to the **COMMIT SETTINGS** command (Image 3.3.3).
- Press the **OK** key.




→	C	O	M	M	I	T		S	E	T	T	I	N	G	S				⏪
	M	O	D	E	=	<							M	A	N	U	A	L	>
	P	R	E	P	U	R	G	E		T	I	M	E	=	<	0	0	5	>
	I	G	N	I	T	I	O	N		T	I	M	E		=	<	3	0	>

Use the Up or Down key and move arrow to **COMMIT SETTINGS**

Image 3.3.3 • SELECT COMMIT SETTINGS

8. After selecting **COMMIT SETTINGS** a confirmation screen (Image 3.3.4) will be displayed to confirm the change(s). Toggle the **LEFT** and **RIGHT** key to **YES** or **NO**.
9. Press the **OK** key to confirm.



3.4 Setting Options

The following section will show the default values and options for each system setting.

3.4.1 BMS Module Menu

Selecting the **BMS MODULE** menu (Image 3.4.1) allows the user to adjust the timing parameters for the ignition sequence, whether the system is in **AUTOMATIC** or **MANUAL** mode, if **PILOT ON DEMAND** is enabled or disabled, and set the **TEMP LIMIT** for the high temperature lockout. Select the **BMS MODULE** menu to see the **BMS MODULE** settings.




Image 3.4.1 • Select BMS MODULE menu

BMS MODULE settings (Image 3.4.2) include: **MODE**, **PREPURGE TIME**, **IGNITION TIME**, **PURGE TIME**, **WAIT TIME**, **IGNITION RETRY**, **WAIT RETRY**, **PILOT EST TIME**, **ONDEMAND**, and **TEMP LIMIT**.




Image 3.4.2 • Select BMS MODULE settings

The following are setting descriptions, settings options and default values for the **BMS MODULE** settings (Table 3.4.1).

SETTING	DESCRIPTION	OPTIONS			DEFAULT
MODE	Chooses between AUTOMATIC and MANUAL mode operation	Mode			AUTOMATIC
		AUTOMATIC			
		MANUAL			
PREPURGE TIME	Duration of the pre-purge period in seconds	Range	Value		5
		Min	0		
		Max	600		
IGNITION TIME	Duration of the ignition period in seconds	Range	Value		30
		Min	1		
		Max	60		
PURGE TIME	Duration of the purge period between ignition periods within the same cycle in seconds	Range	Value		10
		Min	0		
		Max	10		
WAIT TIME	Duration of the wait period in seconds	Range	Value		0
		Min	0		
		Max	1800		
IGNITION RETRY	Number of ignition attempt retries	Range	Value		2
		Min	0		
		Max	3		
WAIT RETRY	Number of wait period retries	Range	Value		2
		Min	0		
		Max	3		
PILOT EST TIME	Length of time required that pilot flame is to be continuously detected before transitioning to the PILOT ON state.	Range	Value		3
		Min	0		
		Max	3		
ONDEMAND	Enables or disables the pilot on demand functionality (only available in AUTOMATIC mode).	Mode			DISABLED
		ENABLED			
		DISABLED			
TEMP LIMIT	Temperature limit of the BMS dual channel thermocouple that triggers a high temperature lockout	Range	°F	°C	1600
		Min	100	38	
		Max	2460	1348	

Table 3.4.1 • BMS MODULE setting descriptions, options and default values

BMS Module Timing Settings

The following graphic (Image 3.4.3) depicts how each ignition timing settings affects the entire ignition sequence.




Image 3.4.3 • BMS module timing settings

System Mode

The **MODE** setting (Image 3.4.4) allows the user to choose between **AUTOMATIC** and **MANUAL** mode. In **AUTOMATIC** mode the system automatically attempts to relight the pilot if flame is lost. In **MANUAL** mode the system will not automatically attempt to relight the pilot.



Image 3.4.4 • Select MODE setting

Pilot On Demand

The **ONDEMAND** setting (Image 3.4.5) enables or disables the pilot on demand feature. When **ONDEMAND** is disabled the system operates as a standing pilot system where the pilot is lit and kept lit while the system is active. When **ONDEMAND** is enabled the pilot is lit when one of the processes is active. If no processes are active, then the pilot is shut-off until a process becomes active. Pilot on demand functionality works with all processes except for the **INDEPENDENT** process.



Image 3.4.5 • Select ONDEMAND setting

High Temperature Lockout

The **TEMP LIMIT** setting (Image 3.4.6) sets the high temperature limit of the BMS Module’s dual-channel thermocouple input which triggers a high temperature lockout when it is reached.



Image 3.4.6 · Select **TEMP LIMIT** setting

3.4.2 Process Menus

There are four **PROCESS** menus (Image 3.4.7) in the system settings. One for each process: 1, 2, 3, and the **INDEPENDENT** process. Select a **PROCESS** menu to see the settings for that process.




Image 3.4.7 · **PROCESS** menus

PROCESS settings (Image 3.4.8) include: **SOURCE**, **LOGIC**, **HIGH LEVEL**, **LOW LEVEL**, **CEILING**, and **FLOOR**.




Image 3.4.8 · Process settings

The following are setting descriptions, settings options and default values for each **PROCESS** setting (Table 3.4.2).

SETTING	DESCRIPTION	OPTIONS		DEFAULT	
SOURCE	Selects which inputs is used as the process current value or process variable	Mode		Process	Default
		Ø (NONE)		1	XDCR
		TC1		2	Ø (NONE)
		TC2		3	Ø (NONE)
		TC BMS		IND	Ø (NONE)
		XDCR			
LOGIC	Selects the logic applied to the high and low levels and the output of the process	Mode		Process	Default
		↑ OFF ↓ ON		1	↑ ON ↓ OFF
		↑ ON ↓ OFF		2	↑ ON ↓ OFF
		WINDOW		3	↑ ON ↓ OFF
		INV WINDOW		IND	↑ ON ↓ OFF
HIGH LEVEL	Selects the process upper threshold value	Range	Value	Process	Default
		Min	-32768	1	50
		Max	32767	2	150
				3	150
				IND	150
LOW LEVEL	Selects the process lower threshold value	Range	Value	Process	Default
		Min	-32768	1	20
		Max	32767	2	120
				3	120
				IND	120
CEILING	Sets the limit of how high the process HIGH LEVEL can be set from the process quick set menu	Range	Value	Process	Default
		Min	-32768	1	55
		Max	32767	2	32767
				3	32767
				IND	32767
FLOOR	Sets the limit of how low the process LOW LEVEL can be set from the process quick set menu	Range	Value	Process	Default
		Min	-32768	1	15
		Max	32767	2	-32768
				3	-32768
				IND	-32768

Table 3.4.2 · PROCESS setting descriptions, options and default values

PROCESS Logic - HIGH OFF LOW ON

The **↑ OFF ↓ ON** process logic selection energizes the output when there is a transition of the **SOURCE** value from above to at or below the **LOW LEVEL** process setting and deenergizes the output when there is a transition from below to at or above the **HIGH LEVEL** process setting (Image 3.4.9).




Image 3.4.9 • PROCESS logic - HIGH OFF LOW ON

PROCESS Logic - HIGH ON LOW OFF

The **↑ ON ↓ OFF** process logic selection deenergizes the output when there is a transition of the **SOURCE** value from above to at or below the **LOW LEVEL** process setting and energizes the output when there is a transition from below to at or above the **HIGH LEVEL** process setting (Image 3.4.10).




Image 3.4.10 • PROCESS logic - HIGH ON LOW OFF

PROCESS Logic - WINDOW

The **WINDOW** process logic selection energizes the output when the **SOURCE** value is at either the **HIGH LEVEL** or **LOW LEVEL** process setting or between them. The output is deenergized when the **SOURCE** value is outside of this window (Image 3.4.11).




Image 3.4.11 • PROCESS logic - WINDOW

PROCESS Logic - INV WINDOW

The **INV WINDOW** process logic selection deenergizes the output when the **SOURCE** value is at either the **HIGH LEVEL** or **LOW LEVEL** process setting or between them. The output is energized when the **SOURCE** value is outside of this window (Image 3.4.12).




Image 3.4.12 • PROCESS logic - INV WINDOW

3.4.3 PID

To set the values of the **PID** settings select the **PID** menu (Image 3.4.13). **Note:** The control output of the **PID** controller is the optional ARControl 4-20 mA module.

Select **PID** menu →

→	≡	P	R	O	C	E	S	S		I	N	D					↵
→	≡	P	I	D													↵
	≡	S	H	U	T	D	O	W	N	1							↵

Image 3.4.13 • PID menu

PID settings (Image 3.4.14) include: **SOURCE**, **SETPOINT**, **P VALUE**, **I VALUE**, **D VALUE**, and **DEADBAND VALUE**.

→	C	O	M	M	I	T		S	E	T	T	I	N	G	S			↵
	S	O	U	R	C	E	=	<									∅	>
	S	E	T	P	O	I	N	T		=	<	+	0	0	0	0	0	>
	P		G	A	I	N					=	<	+	0	0	0	0	>
	I		G	A	I	N					=	<	+	0	0	0	0	>
	D		G	A	I	N					=	<	+	0	0	0	0	>
	D	E	A	D	P	A	N	%				=	<	+	0	0	>	

Image 3.4.14 • PID settings

The following are setting descriptions, settings options and default values for the **PID** settings (Table 3.4.3).

SETTING	DESCRIPTION	OPTIONS		DEFAULT
SOURCE	Sets input to be used as the PID process variable	Mode		Ø (NONE)
		Ø (NONE)		
		TC1		
		TC2		
		TC BMS		
		XDCR		
SETPOINT	The value of the PID setpoint	Range	Value	0
		Min	-32768	
		Max	32767	
P GAIN	The value of the normalized proportional gain in thousandths (gain range is 1 to -1)	Range	Value	0
		Min	-1000	
		Max	1000	
I GAIN	The value of the normalized integral gain in thousandths (gain range is 1 to -1)	Range	Value	0
		Min	-1000	
		Max	1000	
D GAIN	The value of the normalized differential gain in thousandths (gain range is 1 to -1)	Range	Value	0
		Min	-1000	
		Max	1000	
DEADBAND VALUE	The PID error dead band as a percentage of the setpoint value	Range	Value	0
		Min	-10	
		Max	10	

Table 3.4.3 • PID setting descriptions, options and default values

3.4.4 SHUTDOWN Menus

Shutdown logic stops all processes except for the **INDEPENDENT** process. There are three **SHUTDOWN** menus (Image 3.4.15), one for each shutdown: 1, 2, and 3.




Image 3.4.15 • SHUTDOWN menus

SHUTDOWN settings (Image 3.4.16) include: **SOURCE**, **LOGIC**, **HIGH LEVEL**, and **LOW LEVEL**.

→	C	O	M	M	I	T		S	E	T	T	I	N	G	S			↩		
	S	O	U	R	C	E	=	<									∅	>		
	L	O	G	I	C	=	<				↑	O	N		↓	O	F	F	>	
	H	I	G	H		L	E	V	E	L	=	<	+	0	0	0	0	1	>	
	L	O	W			L	E	V	E	L		=	<	+	0	0	0	0	0	>

Image 3.4.16 • SHUTDOWN settings

The following are setting descriptions, settings options and default values for each **SHUTDOWN** setting (Table 3.4.4).

SETTING	DESCRIPTION	OPTIONS		DEFAULT	
SOURCE	Sets the input used as the shutdown process variable. Note: For PS1 and PS2 values see IO Settings	Mode		Shutdown	Default
		∅ (NONE)		1	TC1
		TC1		2	∅ (NONE)
		TC2		3	∅ (NONE)
		TC BMS			
		XDCR			
		PS1			
LOGIC	Selects the logic applied to the high and low levels and the output of the process	Mode		Shutdown	Default
		↑ OFF ↓ ON		1	↑ ON ↓ OFF
		↑ ON ↓ OFF		2	↑ ON ↓ OFF
		WINDOW		3	↑ ON ↓ OFF
		INV WINDOW			
HIGH LEVEL	Selects the shutdown upper threshold value	Range	Value	Shutdown	Default
		Min	-32768	1	1
		Max	32767	2	1
				3	1
LOW LEVEL	Selects the shutdown lower threshold value	Range	Value	Shutdown	Default
		Min	-32768	1	0
		Max	32767	2	0
				3	0

Table 3.4.4 • SHUTDOWN setting descriptions, options and default values

SHUTDOWN Logic - HIGH OFF LOW ON

The **↑ OFF ↓ ON** shutdown logic stops all processes except for the **INDEPENDENT** process when there is a transition of the **SOURCE** value from above to at or below the **LOW LEVEL** shutdown setting and the processes can only be started again once there is a transition from below to at or above the **HIGH LEVEL** shutdown setting (Image 3.4.17).




Image 3.4.17 · SHUTDOWN logic - HIGH OFF LOW ON

SHUTDOWN Logic - HIGH ON LOW OFF

The **↑ ON ↓ OFF** shutdown logic stops all processes except for the **INDEPENDENT** process when there is a transition of the **SOURCE** value from above to at or below the **HIGH LEVEL** shutdown setting and the processes can only be started again once there is a transition from below to at or above the **LOW LEVEL** shutdown setting (Image 3.4.18).




Image 3.4.18 · SHUTDOWN logic - HIGH ON LOW OFF

SHUTDOWN Logic - WINDOW

The **WINDOW** shutdown logic selection stops all processes except for the **INDEPENDENT** process when the **SOURCE** value is at either the **HIGH LEVEL** or **LOW LEVEL** shutdown setting or between them. The processes can only be started again once the **SOURCE** value is outside of this window (Image 3.4.19).




Image 3.4.19 · SHUTDOWN logic - WINDOW

SHUTDOWN Logic - INV WINDOW

The **INV WINDOW** shutdown logic selection stops all processes except for the **INDEPENDENT** process when the **SOURCE** value is above the **HIGH LEVEL** or below the **LOW LEVEL** shutdown setting. The processes can only be started again once the **SOURCE** value is at or between these levels (Image 3.4.20).




Image 3.4.20 · SHUTDOWN logic - INV WINDOW

3.4.5 VALVE TIMING

The **VALVE TIMING** menu is used to set the values for the four valve outputs (Main Valve, Pilot Valve, Valve A and Valve B) settings. To set the values of the **VALVE TIMING** settings select the **VALVE TIMING** menu (Image 3.4.21).



Image 3.4.21 · VALVE TIMING menu

VALVE TIMING settings (Image 3.4.22) include: **DEADTIME**, **DELAY**, and **DUTY**.

Note: **DEADTIME** is used to eliminate valve chatter when control limits are set close to each other. **DELAY** is used to provide a pulse of power to initially open a solenoid valve before starting pulse width modulation. **DUTY** (duty cycle) is used to save power when holding a solenoid valve open.

→	C	O	M	M	I	T		S	E	T	T	I	N	G	S			↩		
	P	I	L	O	T	2		D	U	T	Y			=	<	0	2	5	>	
	M	A	I	N	2			D	E	A	D	T	I	M	E	=	<	0	5	>
	M	A	I	N	2			D	U	T	Y				=	<	0	2	5	>
	M	A	I	N	1			D	E	A	D	T	I	M	E	=	<	0	5	>
	M	A	I	N	1			D	U	T	Y				=	<	0	2	5	>
	P	I	L	O	T	1		D	U	T	Y				=	<	0	2	5	>
	B	M	S	1		V	L	V		D	U	T	Y	=	<	0	2	5	>	
	B	M	S	2		V	L	V		D	U	T	Y	=	<	0	2	5	>	
	P	I	L	O	T	2		D	E	L	A	Y	=	<	0	1	0	0	>	
	P	I	L	O	T	1		D	E	L	A	Y	=	<	0	1	0	0	>	
	M	A	I	N	2			D	E	L	A	Y	=	<	0	1	0	0	>	
	M	A	I	N	1			D	E	L	A	Y	=	<	0	1	0	0	>	
	B	M	S	1		V	L	V		D	L	Y	=	<	0	1	0	0	>	
	B	M	S	2		V	L	V		D	L	Y	=	<	0	1	0	0	>	

Image 3.4.22 · VALVE TIMING settings

The following are setting descriptions, settings options and default values for the **VALVE TIMING** settings (Table 3.4.5).

SETTING	DESCRIPTION	OPTIONS		DEFAULT
PRC 1 DEADTIME	Minimum amount of time in seconds that the valve output must be either active or inactive before it may toggle again	Range	Value	5
		Min	0	
		Max	10	
PRCS 1 DUTY	Duty cycle in % for the valve's PWM operation	Range	Value	25
		Min	25	
		Max	100	
PRC 2 DEADTIME	Same as PRC 1 DEADTIME	Same as PRC 1 DEADTIME		5
PRCS 2 DUTY	Duty cycle in % for the valve's PWM operation	Same as PRCS 1 DUTY		25
PRC 3 DEADTIME	Same as PRC 1 DEADTIME	Range	Value	5
		Min	0	
		Max	1000	
PRCS 3 DUTY	Duty cycle in % for the valve's PWM operation	Same as PRCS 1 DUTY		25
PILOT DUTY	Duty cycle in % for the valve's PWM operation	Same as PRCS 1 DUTY		25
BMS DUTY	Duty cycle in % for the valve's PWM operation	Same as PRCS 1 DUTY		25
PRCS IND DUTY	Duty cycle in % for the valve's PWM operation	Same as PRCS 1 DUTY		25
PRCS IND DELAY	Amount of time in milliseconds that the output is fully on before the valve output starts PWM operation	Range	Value	100
		Min	0	
		Max	1000	
PRCS 1 DELAY	Amount of time in milliseconds that the output is fully on before the valve output starts PWM operation	Same as PRCS IND DELAY		100
PILOT DELAY	Amount of time in milliseconds that the output is fully on before the valve output starts PWM operation	Same as PRCS IND DELAY		100
PRCS 2 DELAY	Amount of time in milliseconds that the output is fully on before the valve output starts PWM operation	Same as PRCS IND DELAY		100
PRCS 3 DELAY	Amount of time in milliseconds that the output is fully on before the valve output starts PWM operation	Same as PRCS IND DELAY		100
BMS DELAY	Amount of time in milliseconds that the output is fully on before the valve output starts PWM operation	Same as PRCS IND DELAY		100

Table 3.4.5 • VALVE TIMING setting descriptions, options and default values

The following graphic (Image 3.4.23) depicts how each valve timing settings affects the entire ignition sequence.




Image 3.4.23 • VALVE TIMING settings

3.4.6 BATTERY LVD (Low Voltage Disconnect)

The **BATTERY LVD** menu (Image 3.4.24) has two settings: **OK LEVEL** and **LOW LEVEL** (Image 3.4.25). When the battery voltage transitions from above to at or below the **LOW LEVEL** setting the system enters the **LOW BATTERY** state in which all processes except for the **INDEPENDENT** process is stopped. The processes can only be started again once the battery voltage transitions from below to at or above the **OK LEVEL** setting.

Select BATTERY LVD menu	≡	V	A	L	V	E		T	I	M	I	N	G			↩
	→	≡	B	A	T	T	E	R	Y		L	V	D			↩
		≡	M	O	D	B	U	S		R	S	4	8	5		↩

Image 3.4.24 • BATTERY LVD menu

→	C	O	M	M	I	T		S	E	T	T	I	N	G	S			↩	
	O	K		L	E	V	E	L				=	<	1	2	5	0	0	>
	L	O	W		L	E	V	E	L			=	<	1	1	5	0	0	>

Image 3.4.25 • BATTERY LVD settings

The following are setting descriptions, settings options and default values for the **BATTERY LVD** settings (Table 3.4.6).

SETTING	DESCRIPTION	OPTIONS		DEFAULT
OK LEVEL	Threshold for battery voltage, in millivolts, that the battery voltage must reach or go above before the LOW BATTERY alarm state can be cleared	Range	Value	12500
		Min	10000	
		Max	30000	
LOW LEVEL	Threshold for battery voltage, in millivolts, that if the battery voltage reaches or goes below the system transitions to the LOW BATTERY alarm state	Range	Value	11500
		Min	10000	
		Max	25000	

Table 3.4.6 · BATTERY LVD setting descriptions, options and default values

The following graphic (Image 3.4.26) depicts the transition when the battery voltage enters and exits the low battery state.




Image 3.4.26 · BATTERY LVD

3.4.7 DATA Logging

The **DATALOG** menu (Image 3.4.27) is used for customization of contract hour, download mode, and log frequency to meet customer or regulatory requirements.




Image 3.4.27 • DATALOG menu

DATALOG settings (Image 3.4.28) include: **CONTRACT HOUR**, **DOWNLOAD MODE**, and **LOG FREQUENCY**.




Image 3.4.28 • DATALOG settings

The following are setting descriptions, options and default values for the **DATALOG** settings (Table 3.4.7).

SETTING	DESCRIPTION		OPTIONS		DEFAULT
CONTRACT HOUR	Contract hour		Range	Value	0
			Min	0	
			Max	23	
DOWNLOAD MODE	Whether all data logs in memory are downloaded or all new data logs since the last retrieval are downloaded		Mode		LAST
			LAST		
			ALL		
LOG FREQUENCY	Sets the frequency, in minutes, at which data logs are created. Recommended settings are below:		Range	Value	60
			Min	5	
			Max	60	
	Recommended Settings		Logs Per Hour		
	5	12			
	6	10			
	10	6			
	12	5			
	15	4			
	20	3			
	30	2			
	60	1			

Table 3.4.7 • DATALOG setting descriptions, options and default values

3.4.8 Transducer Calibration

The **CALIB XDCR** settings allow the system to accurately read many different transducer topologies. Select the **CALIB XDCR** menu (Image 3.4.29) to access the settings. **Note:** Refer to Section 4.6 Transducer Calibration for the steps to calibrate transducers(s).



Image 3.4.29 • CALIB XDCR menu

CALIB XDCR settings (Image 3.4.30) include: **SPAN**, **ZERO**, **UNITS**, and **DECIMAL PLACE**.




Image 3.4.30 • CALIB XDCR settings

The following are setting descriptions, settings options and default values for the **CALIB XDCR** settings (Table 3.4.8).

SETTING	DESCRIPTION		OPTIONS		DEFAULT
SPAN	XDCR Type	SPAN Calculation	Range	Value	800
	BK 422	$\text{Span} = (\text{RANGE}_{\text{xdcr}}) \cdot 10^{\text{DECIMAL PLACE}}$	Min	-32768	
	mV/V	$\text{Span} = (\text{XDCR}_{\text{MAXOUTmV}} / 156.25\text{mV}) \cdot (\text{RANGE}_{\text{xdcr}}) \cdot 10^{\text{DECIMAL PLACE}}$	Max	32767	
	Ratio	$\text{Span} = (\text{RANGE}_{\text{xdcr}}) \cdot 10^{\text{DECIMAL PLACE}}$			
	1-5V	$\text{Span} = (\text{RANGE}_{\text{xdcr}}) \cdot 10^{\text{DECIMAL PLACE}}$			
	4-20mA	$\text{Span} = (\text{RANGE}_{\text{xdcr}}) \cdot 10^{\text{DECIMAL PLACE}}$			
ZERO	Sets the amount of offset to be applied to the XDCR measurement as calibration to “zero out” the measurement		Range	Value	0
			Min	-32768	
			Max	32767	

Table 3.4.8 • CALIB XDCR setting descriptions, options and default values

SETTING	DESCRIPTION			OPTIONS	DEFAULT
UNITS	Selects the units to be display for XDCR values from the following:				oz/in2
	Units	Name	Physical Quantity	Units	
	a.u.	Arbitrary Units	Arbitrary	a.u.	
	oz/in2	Ounce per inch squared	Pressure	oz/in2	
	psi	Pound per inch squared	Pressure	psi	
	kPa	Kilopascal	Pressure	kPa	
	in-H2O	Inches of water	Pressure	in-H2O	
	cm-H2O	Centimeter of water	Pressure	cm-H2O	
	kg/cm2	Kilogram per centimeter squared	Pressure	kg/cm2	
	°F	Degree Fahrenheit	Temperature	°F	
	°C	Degree Celsius	Temperature	°C	
	mV	millivolt	Voltage	mV	
	μA	Microamp	Current	μA	
	%	Percentage	Arbitrary	%	
DECIMAL PLACE	Selects the position of the decimal place displayed for XDCR			Range	Value
				Min	0
				Max	2
	Value		Display Format		
	0		XXXXXX		
	1		XXXX.X		
	2		XXX.XX		
	This is only for display purposes				

Table 3.4.8 • CALIB XDCR setting descriptions, options and default values (continued)

3.4.9 Thermocouple Calibration

The **CALIB TC** settings allow for correction of offset from the thermocouples. The **UNITS** selection allows flexibility throughout international regions. Select the **CALIB TC** menu (Image 3.4.31) to access the settings.



Image 3.4.31 • CALIB TC menu

CALIB TC settings (Image 3.4.32) include: **OFFSET TC1**, **OFFSET TC2**, and **UNITS**.

→	C	O	M	M	I	T		S	E	T	T	I	N	G	S			↩	
	L	I	V	E		T	C		1	=				+	7	1	°	F	>
	O	F	F	S	E	T		T	C	1	=	<	+	0	0	0	0	0	>
	L	I	V	E		T	C		2	=				+	7	1	°	F	>
	O	F	F	S	E	T		T	C	1	=	<	+	0	0	0	0	0	>
	U	N	I	T	S	=	<										°	F	>

Image 3.4.32 • CALIB TC settings

The following are setting descriptions, settings options and default values for the **CALIB TC** settings (Table 3.4.9).

SETTING	DESCRIPTION	OPTIONS		DEFAULT
OFFSET TC1	Sets the amount of offset to be applied to the thermocouple 1 measurement as calibration	Range	Value	0
		Min	-32768	
		Max	32767	
OFFSET TC2	Sets the amount of offset to be applied to the thermocouple 2 measurement as calibration	Range	Value	0
		Min	-32768	
		Max	32767	
UNITS	Selects the units used for thermocouples inputs between Fahrenheit and Celsius	Units		°F
		°F		
		°C		

Table 3.4.9 • CALIB TC setting descriptions, options and default values

3.4.10 IO SETTINGS

The **IO SETTINGS** menu (Image 3.4.33) has six settings (Image 3.4.34): **ALARM** mode, **XDCR TYPE** (transducer type), **PERMISSIVE (DIN)** mode, **PS1** mode, **PS2** mode, and **PS3 PoC (Proof of Closure)** mode. The **ALARM** mode selects if the alarm is normally open or normally closed when inactive. The system is able to interface with numerous transducer types, offering great system flexibility, which are selectable under **XDCR TYPE**, **PERMISSIVE (DIN)**, **PS1**, **PS2**, and **PS3** modes selects if the input detects a normally open or normally closed circuit when inactive. Select the **IO SETTINGS** menu to access the settings.

Select **IO SETTINGS** menu

≡	C	A	L	I	B		T	C									↵
→	≡	I	O		S	E	T	T	I	N	G	S					↵
	≡	U	S	E	R		P	A	S	S	C	O	D	E			↵

Image 3.4.33 • IO SETTINGS menu

→	C	O	M	M	I	T		S	E	T	T	I	N	G	S			↵	
	A	L	A	R	M		M	O	D	E	=	<			N	.	C	.	>
	X	D	C	R		T	Y	P	E	=	<		B	K		4	2	2	>
	D	I	N			M	O	D	E	=	<				N	.	C	.	>
	P	S	1			M	O	D	E	=	<				N	.	O	.	>
	P	S	2			M	O	D	E	=	<				N	.	O	.	>
	P	S	3			M	O	D	E	=	<				N	.	C	.	>

Image 3.4.34 · IO settings

The following are setting descriptions, settings options and default values for the **IO SETTINGS** settings (Table 3.4.10).





SETTING	DESCRIPTION				OPTIONS	DEFAULT
ALARM MODE	Setting	Logical State	Alarm State Reg Value	Electrical State	Mode	N.C.
	Normally Open (N.O.)	Inactive	0	Open 	N.C.	
		Active	1	Closed 	N.O.	
	Normally Closed (N.C.)	Active	1	Open 		
		Inactive	0	Closed 		

Table 3.4.10 · IO setting descriptions, options and default values

SETTING	DESCRIPTION						OPTIONS	DEFAULT
XDCR TYPE	XDCR Type	Range		XDCR Port PWR	Wiring		Mode	BK 422
		Range	Value		XDCR Port	XDCR Wire	BK 422	
	BK 422	Min	0	+5V00	PWR	Power In	mV/V	
		Max	37.5mV		IN+	OUT+	Ratio	
					IN-	OUT-	1-5V	
					GND	GND	4-20mA	
	mV/V	Min	0	+10V0	PWR	Power In		
		Max	156mV		IN+	OUT+		
					IN-	OUT-		
					GND	GND		
	Ratio	Min	0.5V	+5V00	PWR	Power In		
		Max	4.5V		IN+	OUT		
					IN-			
					GND	GND		
	1-5V	Min	1V	+10V0	PWR	Power In		
		Max	5V		IN+	OUT		
					IN-			
					GND	GND		
	4-20mA	Min	4mA	+10V0	PWR	Power In		
		Max	20mA		IN+	OUT		
					IN-			
					GND	GND		

Table 3.4.10 · IO setting descriptions, options and default values (continued)





SETTING	DESCRIPTION			OPTIONS	DEFAULT
PERMSVE (PERMISSIVE) MODE	Setting	Logical State	Electrical State	Mode	N.C.
	Normally Open (N.O.)	Inactive	Open 	N.C.	
		Active	Closed 	N.O.	
	Normally Closed (N.C.)	Active	Open 		
		Inactive	Closed 		
PS1 MODE	Same as PERMISSIVE MODE			Same as PERMISSIVE MODE	N.O.
PS2 MODE	Same as PERMISSIVE MODE			Same as PERMISSIVE MODE	N.O.
PoC (Proof of Closure) MODE	Same as PERMISSIVE MODE			Same as PERMISSIVE MODE	N.C.

Table 3.4.10 • IO setting descriptions, options and default values (continued)

3.4.11 USER PASSCODE

Select the **USER PASSCODE** menu (Image 3.4.35) to access the **USER PASSCODE** settings.




Image 3.4.35 • USER PASSWORD menu

USER PASSCODE settings (Image 3.4.36) include: **PASSCODE** and **ENABLE**.




Image 3.4.36 • PASSCODE settings

The following are setting descriptions, settings options and default values for the **PASSCODE** settings (Table 3.4.11).

SETTING	DESCRIPTION	OPTIONS		DEFAULT
PASSCODE	Sets the passcode to be used to access Settings and Diagnostics Menus	Range	Value	0000
		Min	0000	
		Max	9999	
ENABLE	Enables or disables the use of a passcode to restrict access to Settings and Diagnostics Menus	Mode		DISABLED
		ENABLED		
		DISABLED		

Table 3.4.11 · PASSCODE setting descriptions, options and default values

3.4.12 DISPLAY

Select the **DISPLAY** menu (Image 3.4.37) to access the **DISPLAY** settings.




Image 3.4.37 · DISPLAY menu

DISPLAY settings (Image 3.4.38) include: **TIMEOUT**.



Image 3.4.38 · DISPLAY settings

The following are setting descriptions, settings options and default values for the **DISPLAY** settings (Table 3.4.12).

SETTING	DESCRIPTION	OPTIONS		DEFAULT
DISPLAY	Set the amount of time (in seconds) that the display will remain on after the last menu interaction	Range	Value	1800
		Min	30	
		Max	1800	

Table 3.4.12 · DISPLAY setting descriptions, options and default values

3.4.13 SET DATE & TIME

Select the **SELECT DATE & TIME** menu (Image 3.4.39) to access the date and time settings.



Image 3.4.39 • SET DATE & TIME menu

Follow these steps to set the system date (Image 3.4.40):

1. Use the **LEFT** or **RIGHT** key and enter the month.
2. Press the **OK** key.
3. Use the **LEFT** or **RIGHT** key and enter the day.
4. Press the **OK** key.
5. Use the **LEFT** or **RIGHT** key and enter the year.
6. Press the **OK** key to exit the date setting and enter the time setting.




Image 3.4.40 • Set date

Follow these steps to set the system time (Image 3.4.41):

7. Use the **LEFT** or **RIGHT** key and enter the hour.
8. Press the **OK** key.
9. Use the **LEFT** or **RIGHT** key and enter the minute.
10. Press the **OK** key.
11. Use the **LEFT** or **RIGHT** key and enter AM or PM.
12. Press the **OK** key to return to the system settings menu.




Image 3.4.41 • Set time

3.4.14 SET SITE NAME

Select the **SET SITE NAME** menu (Image 3.4.42) to enter a system site name. A system site name has 20 characters available, is space padded and left justified. Valid characters are 0-9 and A-Z and space. Additionally, the site name must start with the letter and not a number or space.



Image 3.4.42 • SET SITE NAME menu

The first line shows the current site name, in this case it is the default name. The second and third lines show instructions on how to save the name and scroll through the letters. The forth line is used to enter a new site name (Image 3.4.43).




Image 3.4.43 • Enter new site name

Follow these steps to enter a new site name (Image 3.4.44):

- 1. Use the **LEFT** or **RIGHT** key to select the letter or number. **Note:** The first character must be a letter.
- 2. Press, and hold down, on the **RIGHT** key until a prompt appears in the next space.
- 3. Use the **LEFT** or **RIGHT** key to select the next letter or number.
- 4. Repeat steps 1 - 3 until the site name is complete.
- 5. Press the **OK** key to save the new site name and return to the system settings menu.




Image 3.4.44 • Enter new site name steps

3.4.15 FACTORY RESET

Select the **FACTORY RESET** menu (Image 3.4.45) to reset the BMS module to the default factory settings.



Image 3.4.45 • FACTORY RESET menu

On the confirmation screen (Image 3.4.46), press the **LEFT** or **RIGHT** key and toggle **YES** or **NO**. Press the **OK** key to exit.

Note: Factory default values are identified in the tables specific to each setting menu.

N	O	T	I	C	E	!		F	A	C	T	O	R	Y		R	S	T	
S	E	T	T	I	N	G	S		C	A	U	S	E	S		U	N	I	T
T	O		R	E	B	O	O	T											
C	O	N	F	I	R	M		R	E	S	E	T	?		<	N	O		>

Image 3.4.46 • FACTORY RESET menu

3.4.16 MODBUS RTU Over RS-485

The **MODBUS RS-485** menu (Image 3.4.47) is used to setup the settings that allow the system to communicate with most PLCs and other industrial communication equipment.



Image 3.4.47 · MODBUS RS-485 menu

MODBUS RS-485 settings (Image 3.4.48) include: **ADDRESS**, **BAUDRATE**, and **WORD ORDER**.




Image 3.4.48 · MODBUS RS-485 settings

The following are setting descriptions, settings options and default values for the **MODBUS RS-485** settings (Table 3.4.13).

SETTING	DESCRIPTION	OPTIONS		DEFAULT
ADDRESS	Sets the Modbus device address for the system	Range	Value	1
		Min	1	
		Max	247	
BAUDRATE	Baud rate of the ARControl Modbus communications through the Modbus RS-485 port	Mode		19k2
		2400		
		4800		
		9600		
		19k2		
		38k4		
		57k6		
		115k2		
		230k4		
WORD ORDER	Word order of the ARControl Modbus communications through the Modbus RS-485 port	Mode		LSW
		MSW		
		LSW		

Table 3.4.13 · MODBUS RS-485 setting descriptions, options and default values

The following is a **MODBUS RS-485** command type (Table 3.4.14).

REGISTER NUMBER	NAME	DESCRIPTION	PASSCODE to WRITE	DATA TYPE	READ or WRITE
0	STOP COMMAND	Send system to STOPPED state	23917	UINT16	W

Table 3.4.14 · MODBUS RS-485 command type

3.5 MODBUS Register Map

The following section provides the **MODBUS** configuration (Table 3.5.1) and variable (Table 3.5.2) register values.

3.5.1 CONFIGURATION REGISTERS

REGISTER NUMBER	NAME	DESCRIPTION	OPTIONS and REGISTER VALUE		DEFAULT	DATA TYPE	READ or WRITE
0	UNUSED	Unused				N/A	R
1	FIRMWARE VERSION	Current version of the firmware			521	UINT16	R
2	FIRMWARE REVISION	Current revision of the firmware				UINT16	R
3	FIRMWARE CRC MSW	Firmware cyclic redundancy check most significant word				UINT16	R
4	FIRMWARE CRC LSW	Firmware cyclic redundancy check least significant word				UINT16	R
5	MODE	System operation	Mode	Value	0	UINT16	R/W
			MANUAL	1			
			AUTOMATIC	0			
6	PREPURGE TIME	Duration of the pre-purge period in seconds	Range	Value	5	UINT16	R/W
			Min	0			
			Max	600			
7	IGNITION TIME	Duration of the ignition period in seconds	Range	Value	30	UINT16	R/W
			Min	0			
			Max	60			
8	PURGE TIME	Duration of the purge period between ignition periods within the same cycle in seconds	Range	Value	10	UINT16	R/W
			Min	0			
			Max	10			
9	WAIT TIME	Duration of the wait period in seconds	Range	Value	0	UINT16	R/W
			Min	0			
			Max	1800			
10	IGNITION RETRYS	Number of ignition attempt retries	Range	Value	2	UINT16	R/W
			Min	0			
			Max	3			
11	WAIT RETRYS	Number of wait period retries	Range	Value	2	UINT16	R/W
			Min	0			
			Max	3			

Table 3.5.1 • MODBUS register map - configuration registers

REGISTER NUMBER	NAME	DESCRIPTION	OPTIONS and REGISTER VALUE		DEFAULT	DATA TYPE	READ or WRITE
12	PILOT EST TIME	Length of time required that pilot flame is to be continuously detected before transitioning to the PILOT ON state.	Range	Value	3	UINT16	R/W
			Min	0			
			Max	5			
13	PILOT ON DEMAND	Enables or disables the pilot on demand functionality (only available in AUTOMATIC mode).	Mode	Value	0	UINT16	R/W
			ENABLED	1			
			DISABLED	0			
14	BMS HIGH TEMP LIMIT	Temperature limit of the BMS dual channel thermocouple that triggers a high temperature lockout	Range	°F	1600	INT16	R/W
			MIN	100			
			MAX	2460			
15 - 19	UNUSED	Unused				N/A	R
20	PROCESS 1 SOURCE	Input to be used as Process 1 process variable	Source	Value	4	UINT16	R/W
			Ø (NONE)	0			
			TC1	1			
			TC2	2			
			TC BMS	3			
			XDCR	4			
21	PROCESS 1 LOGIC	Operating logic of Process 1	Logic	Value	0	UINT16	R/W
			HIGH ON LOW OFF	0			
			HIGH OFF LOW ON	1			
			WINDOW	2			
			INV WINDOW	3			
22	PROCESS 1 HIGH LEVEL	Process 1 upper limit	Range	Value	50	INT16	R/W
			Min	-32768			
			Max	32768			
23	PROCESS 1 LOW LEVEL	Process 1 lower limit	Range	Value	20	INT16	R/W
			Min	-32768			
			Max	32768			
24	PROCESS 1 CEILING	Upper limit to user adjustable Process 1 high level from the Status Menu (Must be lower than Process 1 High Level)	Range	Value	100	INT16	R/W
			Min	-32768			
			Max	32768			
25	PROCESS 1 FLOOR	Lower limit to user adjustable Process 1 low level from the Status Menu (Must be higher than Process 1 Low Level)	Range	Value	10	INT16	R/W
			Min	-32768			
			Max	32768			

Table 3.5.1 • MODBUS register map - configuration registers (continued)

REGISTER NUMBER	NAME	DESCRIPTION	OPTIONS and REGISTER VALUE		DEFAULT	DATA TYPE	READ or WRITE
26 - 29	UNUSED	Unused				N/A	R
30	PROCESS 2 SOURCE	Input to be used as Process 2 process variable	Source	Value	0	UINT16	R/W
			Ø (NONE)	0			
			TC1	1			
			TC2	2			
			TC BMS	3			
			XDCR	4			
31	PROCESS 2 LOGIC	Operating logic of Process 2	Logic	Value	0	UINT16	R/W
			HIGH ON LOW OFF	0			
			HIGH OFF LOW ON	1			
			WINDOW	2			
			INV WINDOW	3			
32	PROCESS 2 HIGH LEVEL	Process 2 upper limit	Range	Value	150	INT16	R/W
			Min	-32768			
			Max	32768			
33	PROCESS 2 LOW LEVEL	Process 2 lower limit	Range	Value	120	INT16	R/W
			Min	-32768			
			Max	32768			
34	PROCESS 2 CEILING	Upper limit to user adjustable Process 2 high level from the Status Menu (Must be lower than Process 2 High Level)	Range	Value	32767	INT16	R/W
			Min	-32768			
			Max	32768			
35	PROCESS 2 FLOOR	Lower limit to user adjustable Process 2 low level from the Status Menu (Must be higher than Process 2 Low Level)	Range	Value	-32768	INT16	R/W
			Min	-32768			
			Max	32768			
36 - 39	UNUSED	Unused				N/A	R
40	PROCESS 3 SOURCE	Input to be used as Process 3 process variable	Source	Value	0	UINT16	R/W
			Ø (NONE)	0			
			TC1	1			
			TC2	2			
			TC BMS	3			
			XDCR	4			

Table 3.5.1 • MODBUS register map - configuration registers (continued)

REGISTER NUMBER	NAME	DESCRIPTION	OPTIONS and REGISTER VALUE		DEFAULT	DATA TYPE	READ or WRITE
41	PROCESS 3 LOGIC	Operating logic of Process 3	Logic	Value	0	UINT16	R/W
			HIGH ON LOW OFF	0			
			HIGH OFF LOW ON	1			
			WINDOW	2			
			INV WINDOW	3			
42	PROCESS 3 HIGH LEVEL	Process 3 upper limit	Range	Value	150	INT16	R/W
			Min	-32768			
			Max	32768			
43	PROCESS 3 LOW LEVEL	Process 3 lower limit	Range	Value	150	INT16	R/W
			Min	-32768			
			Max	32768			
44	PROCESS 3 CEILING	Upper limit to user adjustable Process 3 high level from the Status Menu (Must be lower than Process 3 High Level)	Range	Value	32767	INT16	R/W
			Min	-32768			
			Max	32768			
45	PROCESS 3 FLOOR	Lower limit to user adjustable Process 3 low level from the Status Menu (Must be higher than Process 3 Low Level)	Range	Value	-32768	INT16	R/W
			Min	-32768			
			Max	32768			
46 - 49	UNUSED	Unused				N/A	R
50	PROCESS IND SOURCE	Input to be used as the Independent Process process variable	Source	Value	0	UINT16	R/W
			Ø (NONE)	0			
			TC1	1			
			TC2	2			
			TC BMS	3			
			XDCR	4			
51	PROCESS IND LOGIC	Operating logic of Independent Process	Logic	Value	0	UINT16	R/W
			HIGH ON LOW OFF	0			
			HIGH OFF LOW ON	1			
			WINDOW	2			
			INV WINDOW	3			

Table 3.5.1 • MODBUS register map - configuration registers (continued)

REGISTER NUMBER	NAME	DESCRIPTION	OPTIONS and REGISTER VALUE		DEFAULT	DATA TYPE	READ or WRITE
52	PROCESS IND HIGH LEVEL	Independent Process upper limit	Range	Value	150	INT16	R/W
			Min	-32768			
			Max	32768			
53	PROCESS IND LOW LEVEL	Independent Process lower limit	Range	Value	120	INT16	R/W
			Min	-32768			
			Max	32768			
54	PROCESS IND CEILING	Upper limit to user adjustable Independent Process high level from the Status Menu (Must be lower than Independent Process High Level)	Range	Value	32767	INT16	R/W
			Min	-32768			
			Max	32768			
55	PROCESS IND FLOOR	Lower limit to user adjustable Independent Process low level from the Status Menu (Must be higher than Independent Process Low Level)	Range	Value	-32768	INT16	R/W
			Min	-32768			
			Max	32768			
56 - 59	UNUSED	Unused				N/A	R
60	PID SOURCE	Input to be used as the PID process variable	Source	Value	0	UINT16	R/W
			Ø (NONE)	0			
			TC1	1			
			TC2	2			
			TC BMS	3			
			XDCR	4			
61	PID SETPOINT	The value of the PID setpoint	Range	Value	0	INT16	R/W
			Min	-32768			
			Max	32768			
62	PID P GAIN	The value of the normalized proportional gain in thousandths (gain range 1 to -1)	Range	Value	0	INT16	R/W
			Min	-1000			
			Max	1000			
63	PID I GAIN	The value of the normalized integral gain in thousandths (gain range 1 to -1)	Range	Value	0	INT16	R/W
			Min	-1000			
			Max	1000			
64	PID D GAIN	The value of the normalized differential gain in thousandths (gain range 1 to -1)	Range	Value	0	UINT16	R/W
			Min	-1000			
			Max	1000			
65	PID DEADBAND VALUE	The PID error dead band as a percentage of the setpoint value	Range	Value	0	UINT16	R/W
			Min	-10			
			Max	10			

Table 3.5.1 • MODBUS register map - configuration registers (continued)

REGISTER NUMBER	NAME	DESCRIPTION	OPTIONS and REGISTER VALUE		DEFAULT	DATA TYPE	READ or WRITE
66 - 69	UNUSED	Unused				N/A	R
70	SHUTDOWN 1 SOURCE	Input used for Shutdown 1	Source	Value	0	UINT16	R/W
			Ø (NONE)	0			
			TC1	1			
			TC2	2			
			TC BMS	3			
			XDCR	4			
			PS1	5			
71	SHUTDOWN 1 LOGIC	Operating logic of Shutdown 1	Logic	Value		UINT16	R
			HIGH ON LOW OFF	0			
			HIGH OFF LOW ON	1			
			WINDOW	2			
			INV WINDOW	3			
72	SHUTDOWN 1 HIGH LEVEL	Shutdown 1 upper limit	Range	Value	1	INT16	R/W
			Min	-32768			
			Max	32767			
73	SHUTDOWN 1 LOW LEVEL	Shutdown 1 lower limit	Range	Value	0	INT16	R/W
			Min	-32768			
			Max	32767			
74 - 79	UNUSED	Unused				N/A	R
80	SHUTDOWN 2 SOURCE	Input used for Shutdown 2	Source	Value	0	UINT16	R/W
			Ø (NONE)	0			
			TC1	1			
			TC2	2			
			TC BMS	3			
			XDCR	4			
			PS1	5			
			PS2	6			

Table 3.5.1 • MODBUS register map - configuration registers (continued)

REGISTER NUMBER	NAME	DESCRIPTION	OPTIONS and REGISTER VALUE		DEFAULT	DATA TYPE	READ or WRITE
81	SHUTDOWN 2 LOGIC	Operating logic of Shutdown 2	Logic	Value	0	UINT16	R/W
			HIGH ON LOW OFF	0			
			HIGH OFF LOW ON	1			
			WINDOW	2			
			INV WINDOW	3			
82	SHUTDOWN 2 HIGH LEVEL	Shutdown 2 upper limit	Range	Value	1	INT16	R/W
			Min	-32768			
			Max	32768			
83	SHUTDOWN 2 LOW LEVEL	Shutdown 2 lower limit	Range	Value	0	INT16	R/W
			Min	-32768			
			Max	32768			
84 - 89	UNUSED	Unused				N/A	R
90	SHUTDOWN 3 SOURCE	Input used for Shutdown 3	Source	Value	0	UINT16	R/W
			Ø (NONE)	0			
			TC1	1			
			TC2	2			
			TC BMS	3			
			XDCR	4			
			PS1	5			
			PS2	6			
91	SHUTDOWN 3 LOGIC	Operating logic of Shutdown 3	Logic	Value	0	UINT16	R/W
			HIGH ON LOW OFF	0			
			HIGH OFF LOW ON	1			
			WINDOW	2			
			INV WINDOW	3			
92	SHUTDOWN 3 HIGH LEVEL	Shutdown 3 upper limit	Range	Value	1	INT16	R/W
			Min	-32768			
			Max	32768			
93	SHUTDOWN 3 LOW LEVEL	Shutdown 3 lower limit	Range	Value	0	UINT16	R/W
			Min	-32768			
			Max	32768			

Table 3.5.1 • MODBUS register map - configuration registers (continued)

REGISTER NUMBER	NAME	DESCRIPTION	OPTIONS and REGISTER VALUE		DEFAULT	DATA TYPE	READ or WRITE
94 - 99	UNUSED	Unused				N/A	R
100	PROCESS 1 VALVE DEADTIME	Minimum amount of time in seconds that the valve output must be either active or inactive before it may toggle again	Range	Value	5	UINT16	R/W
			Min	0			
			Max	10			
101	PROCESS 1 VALVE PWM DUTY CYCLE	Duty cycle in % for the valve's PWM operation	Range	Value	25	UINT16	R/W
			Min	25			
			Max	100			
102	PROCESS 2 VALVE DEAD TIME	Minimum amount of time in seconds that the valve output must be either active or inactive before it may toggle again	Range	Value	5	UINT16	R/W
			Min	0			
			Max	10			
103	PROCESS VALVE 2 PWM DUTY CYCLE	Duty cycle in % for the valve's PWM operation	Range	Value	25	UINT16	R/W
			Min	25			
			Max	100			
104	PROCESS 3 VALVE DEAD TIME	Minimum amount of time in seconds that the valve output must be either active or inactive before it may toggle again	Range	Value	5	UINT16	R/W
			Min	0			
			Max	10			
105	PROCESS 3 VALVE PWM DUTY CYCLE	Duty cycle in % for the valve's PWM operation	Range	Value	25	UINT16	R/W
			Min	25			
			Max	100			
106	PILOT VALVE PWM DUTY CYCLE	Duty cycle in % for the valve's PWM operation	Range	Value	25	UINT16	R/W
			Min	25			
			Max	100			
107	BMS MODULE VALVE PWM DUTY CYCLE	Duty cycle in % for the valve's PWM operation	Range	Value	25	UINT16	R/W
			Min	25			
			Max	100			
108	INDEPENDENT PROCESS VALVE PWM DUTY CYCLE	Duty cycle in % for the valve's PWM operation	Range	Value	25	UINT16	R/W
			Min	25			
			Max	100			
109	INDEPENDENT PROCESS VALVE PWM DELAY	Amount of time in milliseconds that the output is fully on before the valve output starts PWM operation	Range	Value	100	UINT16	R/W
			Min	25			
			Max	100			

Table 3.5.1 • MODBUS register map - configuration registers (continued)

REGISTER NUMBER	NAME	DESCRIPTION	OPTIONS and REGISTER VALUE		DEFAULT	DATA TYPE	READ or WRITE
110	PROCESS 1 VALVE PWM DELAY	Amount of time in milliseconds that the output is fully on before the valve output starts PWM operation	Range	Value	100	UINT16	R/W
			Min	0			
			Max	1000			
111	PILOT VALVE PWM DELAY	Amount of time in milliseconds that the output is fully on before the valve output starts PWM operation	Range	Value	100	UINT16	R/W
			Min	0			
			Max	1000			
112	PROCESS 2 PWM DELAY	Amount of time in milliseconds that the output is fully on before the valve output starts PWM operation	Range	Value	100	UINT16	R/W
			Min	0			
			Max	1000			
113	PROCESS 3 PWM DELAY	Amount of time in milliseconds that the output is fully on before the valve output starts PWM operation	Range	Value	100	UINT16	R/W
			Min	0			
			Max	1000			
114	BMS MODULE VALVE PWM DELAY	Amount of time in milliseconds that the output is fully on before the valve output starts PWM operation	Range	Value	100	UINT16	R/W
			Min	0			
			Max	1000			
115 - 119	UNUSED	Unused				N/A	R
120	BATTERY LVD - OK LEVEL	Threshold for battery voltage, in millivolts, that the battery voltage must reach or go above before the system can clear the LOW BATTERY alarm state	Range	Value	12500	UINT16	R/W
			Min	10000			
			Max	30000			
121	BATTERY LVD - LOW LEVEL	Threshold for battery voltage, in millivolts, that if the battery voltage reaches or goes below cause the system to transition to LOW BATTERY state	Range	Value	11500	UINT16	R/W
			Min	10000			
			Max	25000			
122 - 124	UNUSED	Unused				N/A	R
125	MODBUS ADDRESS	Modbus address of the ARControl through the Modbus RS-485 port	Range	Value	1	UINT16	R/W
			Min	1			
			Max	247			

Table 3.5.1 • MODBUS register map - configuration registers (continued)

REGISTER NUMBER	NAME	DESCRIPTION	OPTIONS and REGISTER VALUE		DEFAULT	DATA TYPE	READ or WRITE
126	MODBUS BAUDRATE	Baud rate of the ARControl Modbus communications through the Modbus RS-485 port	Baud Rate: bits/second	Value	100	UINT16	R/W
			2400	0			
			4800	1			
			9600	2			
			19200	3			
			38400	4			
			57600	5			
			115200	6			
			230400	7			
127	MODBUS WORD ORDER	Word order of the ARControl Modbus communications through the Modbus RS-485 port	Word Order	Value	0	UINT16	R/W
			Most significant word first	1			
			Least significant word first	0			
128 - 129	UNUSED	Unused				N/A	R
130	DATA LOG CONTRACT HOUR	Contract hour	Range	Value	0	UINT16	R/W
			Min	0			
			Max	23			
131	DATA LOG DOWNLOAD MODE	Whether all data logs in memory are downloaded or all new data logs since the last retrieval are downloaded	Range	Value	0	UINT16	R/W
			LAST	0			
			ALL	1			
132	DATA LOG LOG FREQUENCY	The frequency, in minutes, at which data logs are created.	Range	Value	60	UINT16	R/W
			Min	5			
			Max	60			
133 - 134	UNUSED	Unused				N/A	R
135	TRANSDUCER	The span to be applied to the transducer measurement as calibration. See section 4.6 Transducer Calibration	Range	Value	800	INT16	R/W
			Min	-32768			
			Max	32767			
136	TRANSDUCER ZERO	The amount of offset to be applied to the transducer measurement as calibration to “zero out” the measurement	Range	Value	0	INT16	R/W
			Min	-32768			
			Max	32767			

Table 3.5.1 • MODBUS register map - configuration registers (continued)

REGISTER NUMBER	NAME	DESCRIPTION		OPTIONS and REGISTER VALUE		DEFAULT	DATA TYPE	READ or WRITE
137	TRANSDUCER UNITS	The units displayed in the transducer reading	Name	Units	Value	1	UINT16	R/W
			Arbitrary Units	a.u.	0			
			Ounce per inch squared	oz/in ²	1			
			Pound per inch squared	psi	2			
			Kilopascal	kPa	3			
			Inches of water	in-H ₂ O	4			
			Centimeter of water	cm-H ₂ O	5			
			Kilogram per centimeter squared	kg/cm ²	6			
			Degree Fahrenheit	°F	7			
			Degree Celsius	°C	8			
			Millivolt	mV	9			
			Microamp	μA	10			
			Percentage	%	11			
138	TRANSDUCER DECIMAL PLACE	Position of the decimal place displayed in the transducer reading		Range	Value	1	UINT16	R/W
				Min	0			
				Max	2			
139	UNUSED	Unused					N/A	R
140	OFFSET TC1	The amount of offset to be applied to the thermocouple measurement		Range	Value	0	INT16	R/W
				Min	-32768			
				Max	32767			
141	OFFSET TC2	The amount of offset to be applied to the thermocouple measurement		Range	Value	0	INT16	R/W
				Min	-32768			
				Max	32767			
142	TC UNITS	The units used for the thermocouple measurement		Units	Value	0	INT16	R/W
				°F	0			
				°C	1			
143 - 144	UNUSED	Unused		0			N/A	R
145	ALARM MODE	Whether the ALARM output is normally open or normally closed when inactive.		Mode	Value	1	UINT16	R/W
				N.C.	1			
				N.O.	0			

Table 3.5.1 • MODBUS register map - configuration registers (continued)

REGISTER NUMBER	NAME	DESCRIPTION	OPTIONS and REGISTER VALUE		DEFAULT	DATA TYPE	READ or WRITE
146	XDCR TYPE	The type of transducer connected to the Transducer Port	Mode	Value	0	UINT16	R/W
			BK 422	0			
			mV/V	1			
			Ratio	2			
			1-5V	3			
			4-20mA	4			
147	PERMISSIVE INPUT MODE	Whether the PERMISSIVE output is normally open or normally closed when inactive.	Mode	Value	1	INT16	R/W
			N.C.	1			
			N.O.	0			
148	PS1 INPUT MODE	Whether the PS1 output is normally open or normally closed when inactive.	Mode	Value	0	INT16	R/W
			N.C.	1			
			N.O.	0			
149	PS2 INPUT MODE	Whether the PS2 output is normally open or normally closed when inactive.	Mode	Value	0	UINT16	R/W
			N.C.	1			
			N.O.	0			
150	PROOF OF CLOSURE INPUT MODE	Whether the PROOF OF CLOSURE output is normally open or normally closed when inactive.	Mode	Value	1	UINT16	R/W
			N.C.	1			
			N.O.	0			
151 - 154	UNUSED	Unused				N/A	R
155	PASSCODE	Passcode required to access the Settings menu and Diagnostic Info menu	Range	Value	0000	INT16	R/W
			Min	0000			
			Max	9999			
156	PASSCODE ENABLE	Enable or disable the Settings menu and Diagnostic Info menu passcode	Mode	Value	0	INT16	R/W
			Enabled	1			
			Disabled	0			
157 - 159	UNUSED	Unused				N/A	R
160	DISPLAY TIMEOUT	The amount of time in seconds that the display will remain on after the last menu interaction	Range	Value	1800	INT16	R/W
			Min	30			
			Max	1800			

Table 3.5.1 • MODBUS register map - configuration registers (continued)

3.5.2 VARIABLE REGISTERS

REGISTER NUMBER	NAME	DESCRIPTION			DATA TYPE	READ or WRITE
200	CURRENT SYSTEM STATE	Mode	Value in AUTOMATIC mode	Value in MANUAL mode	UINT16	R
		STOPPED	1	1		
		START-UP	2	2		
		DIAGNOSTIC	3	3		
		PRE-PURGE	5	5		
		IGNITE	6	6		
		PURGE	7	N/A		
		WAIT	8	N/A		
		EST PILOT	9	N/A		
		PILOT ON	15	15		
		IDLE	16	16		
		ACTIVE PRCS 1	20	20		
		ACTIVE PRCS 2	21	21		
		ACTIVE PRCS 3	22	22		
		ACTIVE PRCS 1,2	25	25		
		ACTIVE PRCS 1,3	26	26		
		ACTIVE PRCS 2,3	27	27		
		ACTIVE PRCS ALL	30	30		
		PILOT FAIL	35	35		
		POC FAIL	36	36		
		LOW BATTERY	37	37		
		PERMISSIVEOPEN	38	38		
		SHUTDOWN 1	40	40		
		SHUTDOWN 2	41	41		
		SHUTDOWN 3	42	42		
		BMS FAULT	45	45		

Table 3.5.2 • MODBUS register map - variable registers

REGISTER NUMBER	NAME	DESCRIPTION		DATA TYPE	READ or WRITE
201	PROCESS 1 VALUE	Range	Value	INT16	R
		Min	-32768		
		Max	32767		
202	PROCESS 2 VALUE	Range	Value	INT16	R
		Min	-32768		
		Max	32767		
203	PROCESS 3 VALUE	Range	Value	INT16	R
		Min	-32768		
		Max	32767		
204	PROCESS IND VALUE	Range	Value	INT16	R
		Min	-32768		
		Max	32767		
205	SHUTDOWN 1 VALUE	Range	Value	INT16	R
		Min	-32768		
		Max	32767		
206	SHUTDOWN 2 VALUE	Range	Value	INT16	R
		Min	-32768		
		Max	32767		
207	SHUTDOWN 3 VALUE	Range	Value	INT16	R
		Min	-32768		
		Max	32767		
208	PID PROCESS VALUE	Range	Value	INT16	R
		Min	-32768		
		Max	32767		
209	PID CONTROL VALUE	Range	Value	INT16	R
		Min	-100		
		Max	100		
210	TC 1 VALUE	Range	Value	INT16	R
		Min	-32768		
		Max	32768		
211	TC 2 VALUE	Range	Value	INT16	R
		Min	-32768		
		Max	32767		

Table 3.5.2 • MODBUS register map - variable registers

REGISTER NUMBER	NAME	DESCRIPTION		DATA TYPE	READ or WRITE
212	TC BMS MODULE VALUE	Range	Value	INT16	R
		Min	-32768		
		Max	32767		
213	TRANSDUCER VALUE	Range	Value	INT16	R
		Min	-32768		
		Max	32767		
214	UNUSED	Unused		N/A	R
215	PS 1 STATE	Range	Value	UINT16	R
		Active	1		
		Inactive	0		
216	PS 2 STATE	Range	Value	UINT16	R
		Active	1		
		Inactive	0		
217	PROOF OF CLOSURE STATE	Range	Value	UINT16	R
		Active	1		
		Inactive	0		
218	IND PROCESS VALVE STATE	Range	Value	UINT16	R
		Active	1		
		Inactive	0		
219	UNUSED	Unused		N/A	R
220	PROCESS 1 VALVE STATE	Range	Value	UINT16	R
		Active	1		
		Inactive	0		
221	PILOT VALVE STATE	Range	Value	UINT16	R
		Active	1		
		Inactive	0		
222	PROCESS 2 VALVE STATE	Range	Value	UINT16	R
		Active	1		
		Inactive	0		
223	PROCESS 3 VALVE STATE	Range	Value	UINT16	R
		Active	1		
		Inactive	0		
224	PILOT STATUS OUTPUT STATE	Range	Value	UINT16	R
		Active	1		
		Inactive	0		

Table 3.5.2 • MODBUS register map - variable registers

REGISTER NUMBER	NAME	DESCRIPTION		DATA TYPE	READ or WRITE
225	INDEPENDENT PROCESS VALVE STATE	Range	Value	UINT16	R
		Active	1		
		Inactive	0		
226	ALARM STATE	Range	Value	UINT16	R
		Active	1		
		Inactive	0		
227 - 229	UNUSED	Unused		N/A	R
230	BATTERY VOLTAGE	Range	Value	UINT16	R
		Min	0		
		Max	65535		
231	SOLAR VOLTAGE	Range	Value	UINT16	R
		Min	0		
		Max	65535		
232	AMBIENT TEMPERATURE	Range	Value	INT16	R
		Min	-32768		
		Max	32767		
233 - 234	UNUSED	Unused		N/A	R
235	FLAME SENSE GRADE	Range	Value	UINT16	R
		Min	0		
		Max	100		
236	BMS MODULE VALVE STATE	Range	Value	UINT16	R
		Active	1		
		Inactive	0		

Table 3.5.2 • MODBUS register map - variable registers

REGISTER NUMBER	NAME	DESCRIPTION	DATA TYPE	READ or WRITE																								
237	BMS MODULE LOCKOUT TYPE	The BMS Module lockout types register reports all the current lockouts or faults in the BMS Module as the summation of the values for the individual lockout codes shown in the table below:	UINT16	R																								
		<table><tr><th>Value</th><th>Lockout</th></tr><tr><td>1</td><td>BIST</td></tr><tr><td>2</td><td>High Temperature</td></tr><tr><td>4</td><td>Fuel Means Fault</td></tr><tr><td>8</td><td>Recycle Lockout</td></tr><tr><td>16</td><td>Thermocouple Open Fault</td></tr><tr><td>32</td><td>Thermocouple Wiring Fault</td></tr><tr><td>64</td><td>Thermocouple Difference</td></tr><tr><td>128</td><td>Flame Sense Fault</td></tr><tr><td>256</td><td>EEPROM Fault</td></tr><tr><td>512</td><td>ADC Fault</td></tr><tr><td>1024</td><td>Communication Lost Lockout</td></tr></table>			Value	Lockout	1	BIST	2	High Temperature	4	Fuel Means Fault	8	Recycle Lockout	16	Thermocouple Open Fault	32	Thermocouple Wiring Fault	64	Thermocouple Difference	128	Flame Sense Fault	256	EEPROM Fault	512	ADC Fault	1024	Communication Lost Lockout
		Value			Lockout																							
		1			BIST																							
		2			High Temperature																							
		4			Fuel Means Fault																							
		8			Recycle Lockout																							
		16			Thermocouple Open Fault																							
		32			Thermocouple Wiring Fault																							
		64			Thermocouple Difference																							
		128			Flame Sense Fault																							
		256			EEPROM Fault																							
		512			ADC Fault																							
		1024			Communication Lost Lockout																							
		Example: If the system detects an ADC fault and thermocouple goes open this register would report 512 + 16 = 528.																										
		<table><tr><th>Range</th><th>Value</th></tr><tr><td>Min</td><td>0</td></tr><tr><td>Max</td><td>65535</td></tr></table>			Range	Value	Min	0	Max	65535																		
Range	Value																											
Min	0																											
Max	65535																											

Table 3.5.2 • MODBUS register map - variable registers

3.6 Data Logs

The system can create and store two types of data logs (**Note:** Both log types contain the same data):

- Time-based: Logs are generated at the rate set in the **LOG FREQUENCY** setting.
- Event-based: Logs are generated when events of special interest happen in the system.

Data is broken down into the following groups:

- System Data (Table 3.6.1)
- Process 1 Data (Table 3.6.2)
- Process 2 Data (Table 3.6.2)
- Process 3 Data (Table 3.6.2)
- Independent Process Data (Table 3.6.2)
- Shutdown 1 Data (Table 3.6.3)
- Shutdown 2 Data (Table 3.6.3)
- Shutdown 3 Data (Table 3.6.3)
- Digital Data (Table 3.6.4)
- Analog Data (Table 3.6.4).

GROUP	HEADER	DESCRIPTION
SYSTEM DATA	TIME STAMP	Time stamp in the format YYYYMMddhhmmss. This time stamp format facilitates data manipulation and plotting.
	DATE	Date of the data log
	TIME	Time of the data log
	LOG TYPE	Event that triggered the data log (Power on, power off, state change, alarm, erase logs, etc...)
	MODE	System mode (MANUAL, AUTOMATIC)
	STATE	System state (STOPPED, PILOT ON, BMS FAULT , etc...)
	LOCKOUT TYPE	BMS Module lockout type
	ONDEMAND	Pilot On Demand setting state
	PILOT VALVE	State of pilot valve (ACTIVE, INACTIVE)

Table 3.6.1 • System data

GROUP	HEADER	DESCRIPTION
PROCESS 1, 2, 3 or INDEPENDENT (Note: Each process has unique data)	LOGIC	Process logic setting (HIGH ON LOW OFF, HYTERESIS , etc...)
	SOURCE	Process source setting (TC1, TC2, XDCR, PS2 , etc...)
	CURRENT VALUE	Value of process source at time of log
	HIGH LEVEL	Process high level setting
	LOW LEVEL	Process low level setting
	PRCS 1, 2 or 3 VLV	Process valve state

Table 3.6.2 • Process 1, 2, 3 or INDEPENDENT data

GROUP	HEADER	DESCRIPTION
SHUTDOWN 1, 2, or 3 (Note: Each shutdown has unique data)	LOGIC	Shutdown logic setting
	SOURCE	Shutdown source setting
	CURRENT VALUE	Value of shutdown source
	HIGH LEVEL	Shutdown high level setting
	LOW LEVEL	Shutdown low level setting

Table 3.6.3 • Shutdown 1, 2, or 3 data

GROUP	HEADER	DESCRIPTION
DIGITAL DATA	FLAME INDICATOR	State of PILOT STATUS output
	ALARM	State of Alarm output
	ALARM MODE	Mode of Alarm output (N.O., N.C.)
	SWITCH 1	PS1 input state (Active, Inactive)
	SWITCH 1 MODE	Mode of PS1 input (N.O., N.C.)
	SWITCH 2	PS2 input state
	SWITCH 2 MODE	Mode of PS2 input
	POC	PROOF OF CLOSURE input state
	POC MODE	Mode of PROOF OF CLOSURE Input
	PERMISSIVE	PERMISSIVE input state
	PERMISSIVE MODE	Mode of PERMISSIVE input
	FLAMESENSE GRADE	Grade of flame sense (A, B, C, D, F)

Table 3.6.4 • Digital data

GROUP	HEADER	DESCRIPTION
ANALOG DATA	TEMPERATURE UNITS	System temperature units (FAHRENHEIT, CELSIUS)
	AMBIENT TEMPERATURE	Ambient temperature inside of the enclosure
	THERMOCOUPLE 1	Thermocouple 1 temperature
	THERMOCOUPLE 2	Thermocouple 2 temperature
	THERMOCOUPLE BMS	Temperature of the BMS Module thermocouple
	TRANSDUCER	Transducer value. Does not show decimal point
	TRANSDUCER UNITS	Tranducer units (psi, oz/in ² , etc...)
	PID SETPOINT	Setpoint of the PID controller
	PID CONTROL VARIABLE	Control variable of the PID controller (current value of input)
	BATTERY VOLTAGE	Battery voltage in volts
	SOLAR VOLTAGE	Solar voltage in volts

Table 3.6.5 • Analog data


The following is a list of events logged by the system (Table 3.4.18).

EVENT	DESCRIPTION
LOGS ERASED	All previously logs erased
POWER ON	Unit has been powered on
POWER OFF	Unit was powered off
INTERVAL	The time period set in the LOG FREQUENCY has elapsed.
DATA DOWNLOAD	Previous data has been downloaded
SETTINGS CHANGE	System settings have changed
FIRMWARE UPDATE	Firmware has been updated to a new revision
STATE CHANGE	System state has changed

Table 3.4.18 • Events logged by the system

3.6.1 Retrieving the Data Logs

The data logs are easily retrieved by inserting a USB drive (FAT formatted) into the USB drive port on the ARControl unit. The system will write the data logs to a CSV file under a folder named ARControl on the root of the USB drive. The CSV log file is named after the time the log was generated in the format YYYYMMddhhmmss (Image 3.6.1).



Data log file

Image 3.6.1 • Data log file

3.6.2 Clearing the Data Logs

Select the **CLEAR DATA LOGS** menu (Image 3.6.2) to clear the data logs.



Image 3.6.2 • CLEAR DATA LOGS menu

On the confirmation screen (Image 3.6.3), press the **LEFT** or **RIGHT** key and toggle **YES** or **NO**. Press the **OK** key to exit. **Important!** Cleared data cannot be recovered.




Image 3.6.3 • Confirm clearing data log

4 System Operation

⚠ WARNING!

Failure to comply with the following safety warning(s) may result in serious personal injury or death.

- Do not open the unit when in operational mode.

Each mode of operation, **AUTOMATIC** and **MANUAL** have multiple operation and alarm states. Additionally, The system has an **INDEPENDENT (PI)** process which is a process that continually runs if the system is powered on and is not in the **DIAGNOSTIC** mode. The independent process will continue even if the system is in the **STOPPED** state or even an **ALARM** or **SHUTDOWN** state.

Information about the current state and prompts for actionable menu items is presented in the system menu state additional information entry (**STATE ADDTL INFO**) (Table 4.1). This section provides detailed information about each mode, states and transitions between states.

Current operation state	→	S	T	A	T	E	=	[C	U	R	R			S	T	A	T	E]	Additional state information		
		[S	T	A	T	E		A	D	D	T	L		I	N	F	O]			
Current mode	≡	P ₁	=					[C	U	R	R			V	A	L	U	E]	↵	INDEPENDENT process information	
	≡	P ₂	=					[C	U	R	R			V	A	L	U	E]	↵		
	≡	P ₃	=					[C	U	R	R			V	A	L	U	E]	↵		
	≡	P _I	=					[C	U	R	R			V	A	L	U	E]	↵		
		M	O	D	E	=			[C	U	R	R	E	N	T		M	O	D	E]
	≡	D	I	A	G	N	O	S	T	I	C	S			I	N	F	O		↵			

Image 4.1 • System Menu

4.1 AUTOMATIC Mode

In **AUTOMATIC** mode ignition is initiated by the user. Upon power-up in **AUTOMATIC** mode, the system initializes in the **STOPPED** state (Image 4.1.1). Once the pilot is lit, the system will automatically start controlling the process (Image 4.1.2). The system will attempt to automatically relight if flame is lost (A). **ON DEMAND** mode is also available which only lights the pilot when flame is required by a process.

If the system is in any state except for an alarm state, the system can transition to the **STOPPED** state by pressing the **STOP** button. To exit the **STOPPED** state the user must navigate to the **START (HOLD OK)** ↵ menu entry and hold the **OK** key for at least a second. Once the **OK** key is released the system will transition to the **STARTUP** state (B) or, if in the **ONDEMAND** mode, to the **IDLE** state (B).

→	S	T	A	T	E	=								S	T	O	P	P	E	D
	S	T	A	R	T				(H	O	L	D		O	K)			↵
≡	P ₁	=												0	.	0	⁰ / ₂		in	²
≡	P ₂	=																		∅

Image 4.1.1 • System Menu - AUTOMATIC start-up




Image 4.1.2 · AUTOMATIC mode flow diagram

The **AUTOMATIC** mode has the following operational states (Table 4.1.1):

AUTOMATIC OPERATIONAL STATES		
STATE	DISPLAY	DESCRIPTION
STOPPED	STOPPED	In the STOPPED state, the system closes all valves and activates the ALARM output. If ON DEMAND is disabled and the user initiates the system by pressing and holding the OK button for a second or more, the system will transition to the START-UP state. If ON DEMAND is enabled and the user initiates the system by pressing and holding the OK button for a second or more, the system will transition to the IDLE state.
START-UP	START-UP	In the START-UP state the system checks the input PS3 (Proof of Closure). If the input is active then the system transitions to the POC FAILURE state, if it is inactive the system transitions to the PRE-PURGE state.
PRE-PURGE	PRE-PURGE	In the PRE-PURGE state, the system delays for the PREPURGE TIME before transitioning to the IGNITING state and the IGNITION RETRY(s) are reset. The PRE-PURGE state provides time for the system to purge itself of unignited gas.
IGNITE	IGNITE	In the IGNITE state, the system begins ignition, opens the ESD and Pilot valves, and then continues to ignite for the IGNITION TIME or until flame is detected. If flame is detected the system will transition to the ESTABLISHING PILOT state. If the ignition time expires before flame is detected, then the system will transition to the PURGE state.
PURGE	PURGE	In the PURGE state, the system closes all valves. If there are IGNITION RETRY(s) remaining, the system delays for the PURGE TIME before transitioning to the IGNITE state. If there are no IGNITION RETRY(s) remaining, the system transitions to the WAIT state. The PURGE state is intended to provide time for the system to purge itself of unignited gas.
WAIT	WAIT	In the WAIT state, the system closes all valves. If there are WAIT RETRY(s) remaining, the system delays for the WAIT TIME before transitioning to the PRE-PURGE state. If there are no WAIT RETRY(s) remaining, the system transitions to the PILOT FAILURE state.
ESTABLISH PILOT	EST PILOT	In the EST PILOT state, the system checks for the continuous presence of flame for the PILOT EST TIME . If the flame is continuously present for the PILOT EST TIME , the system transitions to the PILOT ON state. If flame is lost during the PILOT EST TIME , the system resets the IGNITION RETRY(s) and transitions to the IGNITION state.
PILOT ON	PILOT ON	In the PILOT ON state, the system will wait to transition to an ACTIVE state until one of the processes becomes active. If flame is lost in the PILOT ON state, the system resets the IGNITION RETRY(s) and transitions to the IGNITION state.
IDLE	IDLE	In the IDLE state, the system closes all valves and waits indefinitely until a process becomes active. If a process becomes active, the system will transition to the START-UP state.
ACTIVE 1	ACTIVE PRCS 1	In any of the ACTIVE states, the system continually checks the state of all processes. If a process becomes active, the system will open the process' valve and update the state name accordingly. If any process becomes inactive, the system will close that process' valve and update the state name accordingly. If all processes become inactive, the system will transition back to the PILOT ON state if ON DEMAND is disabled or to the IDLE state of ON DEMAND is enabled.
ACTIVE 2	ACTIVE PRCS 2	
ACTIVE 3	ACTIVE PRCS 3	
ACTIVE 1+2	ACTIVE PRCS 1,2	
ACTIVE 1+3	ACTIVE PRCS 1,3	
ACTIVE 2+3	ACTIVE PRCS 2,3	
ACTIVE 1+2+3	ACTIVE PRCS ALL	

Table 4.1.1 • AUTOMATIC operational states

Information about the current state and prompts for actionable menu items is presented in the system menu state additional information entry (**STATE ADDTL INFO**) (Table 4.1.2).

AUTOMATIC MODE		
OPERATION STATE	SYSTEM MENU DISPLAY	DESCRIPTION
STOPPED	START (HOLD OK)	Actionable menu item: START (HOLD OK)
START-UP	CHECKING SYSTEM...	Indicates system is checking the input PS3 (Proof of Closure)
PRE-PURGE	mm:ss	Displays pre-purge time before transitioning to the IGNITE state (minutes : seconds)
IGNITE	mm:ss	Displays the remaining ignition time (minutes : seconds)
PURGE	IGN RETRY=XX mm:ss	Displays the remaining purge time and number of ignition retries remaining (minutes : seconds)
WAIT	WAIT RETRY=XX mm:ss	Displays the wait time if there are WAIT retry(s) remaining (minutes : seconds)
EST PILOT	mm:ss	Displays the remaining time that the system will check for the continuous presence of flame (minutes : seconds)
PILOT ON	DDDDDDDDDD:hh:mm:ss	Displays elapsed time the Pilot is on (days: hour: minutes : seconds)
IDLE	DDDDDDDDDD:hh:mm:ss	Displays elapsed time the system is idle (days: hour: minutes : seconds)
ACTIVE PRCS 1	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 (days: hour: minutes : seconds)
ACTIVE PRCS 2	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 2 (days: hour: minutes : seconds)
ACTIVE PRCS 3	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 3 (days: hour: minutes : seconds)
ACTIVE PRCS 1,2	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 & 2 (days: hour: minutes : seconds)
ACTIVE PRCS 1,3	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 & 3 (days: hour: minutes : seconds)
ACTIVE PRCS 2,3	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 2 & 3 (days: hour: minutes : seconds)
ACTIVE PRCS ALL	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 & 2 & 3 (days: hour: minutes : seconds)

Table 4.1.2 · AUTOMATIC state additional information

4.2 MANUAL Mode

In **MANUAL** mode the duration of ignition is manually controlled by the user (Image 4.2.1). Once the pilot is lit, the user must initiate the process control. The system will not attempt to automatically relight if flame is lost. **ON DEMAND** mode is not available in **MANUAL** mode operation.

→	S	T	A	T	E	=					S	T	O	P	P	E	D
	H	O	L	D	O	K	+	→	2		I	G	N	I	T	E	↵
≡	P ₁	=									0	.	0	0	2	in	2
≡	P ₂	=															Ø

Image 4.2.1 · System Menu - MANUAL start-up

Upon power-up in **MANUAL** mode (Image 4.2.2), the system starts in the **STOPPED** state (A). If the system is in any state except for an alarm state, the system can transition to the **STOPPED** state by pressing the **STOP** button. To exit the **STOPPED** state the user must navigate to the **HOLD OK+→ 2 STRT ↵** menu entry and hold the **OK** and **→** keys. While holding the **OK** and **→** keys the system will transition through the **PRE-PURGE** state (B) into the **IGNITE** state (C). The system will remain in the **IGNITE** state for up to 60 seconds while the user is holding the **OK** and **→** keys or until pilot flame is detected. Once flame is detected the display will prompt **START PROCESSES ↵**. At this time the user can begin the processes by pressing **OK**.




Image 4.2.2 • MANUAL mode flow diagram

The **MANUAL** mode has the following operational states (Table 4.2.1):

MANUAL OPERATION MODES		
STATE	DISPLAY	DESCRIPTION
STOPPED	STOPPED	In the STOPPED state, the system closes all valves and activates the ALARM output. If the user initiates the system by pressing and holding the OK and → keys for a second or more, the system will transition to the START-UP state.
START-UP	START-UP	In the START-UP state the system checks the input PS3 (Proof of Closure). If the input is active then the system transitions to the POC FAILURE state. If the input is inactive the user is still holding OK and → keys, the system transitions to the PRE-PURGE state.
PRE-PURGE	PRE-PURGE	In the PRE-PURGE state, if the user is still holding the OK and → keys, the system delays for the PREPURGE TIME before transitioning to the IGNITING state. The PRE-PURGE state is intended to provide time for the system to purge itself of unignited gas.
IGNITE	IGNITE	In the IGNITE state, if the user is still holding the OK and → keys, the system begins ignition, opens the ESD and Pilot valves, and then continues to ignite for up to 60 seconds or until flame is detected. If flame is detected the system will transition to the IDLE state. If the ignition time expires before flame is detected or the user releases the OK and → keys, then the system will transition to the STOPPED state.
PILOT ON	PILOT ON	In the PILOT ON state, the system will wait to transition to an ACTIVE state until one of the processes becomes active. If pilot flame is lost, the system will transition to the STOPPED state
IDLE	IDLE	In the IDLE state, the system waits for the user to press the OK key in order to begin the processes. If the user presses the OK key, the system will transition to the PILOT ON state.
ACTIVE 1	ACTIVE PRCS 1	In any of the ACTIVE states, the system continually checks the state of all processes. If a process becomes active, the system will open the process' valve and update the state name accordingly. If any process becomes inactive, the system will close that process' valve and update the state name accordingly. If all processes become inactive, the system will transition back to the PILOT ON state. If pilot flame is lost, the system will transition to the STOPPED state.
ACTIVE 2	ACTIVE PRCS 2	
ACTIVE 3	ACTIVE PRCS 3	
ACTIVE 1+2	ACTIVE PRCS 1,2	
ACTIVE 1+3	ACTIVE PRCS 1,3	
ACTIVE 2+3	ACTIVE PRCS 2,3	
ACTIVE 1+2+3	ACTIVE PRCS ALL	

Table 4.2.1 • **MANUAL** operational states

Information about the current state and prompts for actionable menu items is presented in the system menu state additional information entry (**STATE ADDTL INFO**) (Table 4.2.2).

MANUAL MODE		
OPERATION STATE	SYSTEM MENU DISPLAY	DESCRIPTION
STOPPED	HOLD OK↔ 2 STRT ↵	Actionable menu item: Hold the OK key for at least a second to start ignition
START-UP	CHECKING SYSTEM...	Indicates system is checking the input PS3 (Proof of Closure)
PRE-PURGE	mm:ss	Displays pre-purge time before transitioning to the IGNITE state (minutes : seconds)
IGNITE	mm:ss	Displays the remaining ignition time (minutes : seconds)
PILOT ON	DDDDDDDDDD:hh:mm:ss	Displays elapsed time the Pilot is on (days: hour: minutes : seconds)
IDLE	DDDDDDDDDD:hh:mm:ss	Displays elapsed time the system is idle (days: hour: minutes : seconds)
ACTIVE PRCS 1	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 (days: hour: minutes : seconds)
ACTIVE PRCS 2	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 2 (days: hour: minutes : seconds)
ACTIVE PRCS 3	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 3 (days: hour: minutes : seconds)
ACTIVE PRCS 1,2	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 & 2 (days: hour: minutes : seconds)
ACTIVE PRCS 1,3	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 & 3 (days: hour: minutes : seconds)
ACTIVE PRCS 2,3	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 2 & 3 (days: hour: minutes : seconds)
ACTIVE PRCS ALL	DDDDDDDDDD:hh:mm:ss	Displays elapsed time for Process 1 & 2 & 3 (days: hour: minutes : seconds)

Table 4.1.2 • MANUAL state additional information

4.3 Alarm & Shutdown States

4.3.1 Alarm States

Both alarms and shutdowns will stop the system processes if certain conditions are met. The system monitors various parameters for undesirable conditions, some of which are configurable, and will enter an alarm state (Image 4.3.1) if those conditions are met. This is to ensure proper operation of the system and control of the processes.




Image 4.3.1 • Example of alarm state

Alarms stop the system, regardless of what state it is in, if the permissive is active, battery voltage is low, failure to light the pilot, proof of valve closure was not proved, or the high temperature limit reached. In all alarm states the system closes all valves, except for the **INDEPENDENT** process, and activates the **ALARM** output. The system will transition to the **STOPPED** state once the alarm is cleared (Image 4.3.2).




Image 4.3.2 · Alarm & shutdown states

Both **AUTOMATIC** and **MANUAL** modes have the following alarm states (Table 4.3.1):

ALARM STATE	DESCRIPTION
PILOT FAILURE	The system will enter the PILOT FAILURE alarm state if it has not been able to establish pilot flame and there is no IGNITION RETRY(s) and RECYCLE RETRY(s) remaining. The system will remain in this state indefinitely or until the user clears the alarm.
PROOF OF CLOSURE (POC) FAILURE	The system will enter the POC FAILURE alarm state if the Proof of Closure input is active during the START-UP state. The system will remain in this state indefinitely or until the user clears the alarm.
LOW BATTERY	The system continually monitors the BATTERY-IN input voltage. The system will enter the LOW BATTERY alarm state if the voltage detected at the BATTERY-IN input drops to or below the BATTERY LVD -> LOW LEVEL . The system will remain in this state indefinitely or until the voltage detected at the BATTERY-IN input is at or above the BATTERY LVD -> OK LEVEL and the user clears the alarm.
PERMISSIVE OPEN	The system continually monitors the Permissive input. The system will enter the PERMISSIVE OPEN alarm state if the Permissive input becomes active. The system will remain in this state indefinitely or until the Permissive input is no longer active and the user clears the alarm.
BMS FAULT	The BMS Module continually runs self-test to ensure its proper operation. It continually reports the status of these test to the ARControl. The system will enter a BMS FAULT alarm state if the BMS Module has detected a lockout condition or if the system stops receiving communication from the BMS Module. The system will remain in this state until the BMS Module lockout condition is remedied and the user clears the alarm.

Table 4.3.1 · Alarm states

4.3.2 Shutdown States

Shutdowns stop the system if the system is in an **ACTIVE** state and the user-defined conditions of the shutdown are met.

The system has three highly configurable shutdowns which monitor the system during the **ACTIVE**, **PILOT ON**, or **IDLE** states for triggerable conditions. If the triggerable conditions are met, the system will enter the **SHUTDOWN** state in which all valves, except for the **INDEPENDENT** process, are closed and the **ALARM** output is activated. This allows for the system to be shut down for conditions such as over-temperature, over-pressure, high- or low-level limits, **PS1** or **PS2** input changes, and more. The system will remain in this state until the user clears the alarm. The system will transition to the **STOPPED** state once the alarm is cleared.

SHUTDOWN STATE	DESCRIPTION
SHUTDOWN 1	The system will enter a SHUTDOWN state if any of the SHUTDOWN(s) conditions are met while the system is in any of the ACTIVE , PILOT ON , or IDLE states. In the SHUTDOWN state, the system closes all valves, except for the independent process valve, and activates the ALARM output. The system will remain in this state until the user clears the alarm. The system will transition to the STOPPED state once the alarm is cleared.
SHUTDOWN 2	
SHUTDOWN 3	

Table 4.3.2 · Shutdown states

4.4 INDEPENDENT Process

The **INDEPENDENT** process runs independently of all other system states including **ALARM** and **SHUTDOWN** states. It continually runs if the system is powered ON and is not in the **DIAGNOSTIC** mode. The **INDEPENDENT** process will continue even if the system is in the **STOPPED** state or even an **ALARM** or **SHUTDOWN** state. It is only inactive in **DIAGNOSTIC** mode.

4.5 PID Control Loop

The system has a PID control loop which is utilized along with the accessory ARControl 4-20 mA module. The PID controller allows for precise and stable closed-loop-control that is tolerant to system error. The PID controller requires tuning which is best performed by personnel with PID tuning experience. The PID control loop runs at all times, even in **DIAGNOSTIC** mode.




Image 4.5.1 • PID control loop

4.6 Transducer Calibration

Follow these steps to calibrate a transducer:

Identify the transducer output type.

Note: The ARControl can read Barksdale 422 series, mV/V, Ratiometric, 1-5V, and 4-20mA output type transducers. The ARControl BMS provides non-incentive connections for external Barksdale 422-series pressure transducers. These transducers have been evaluated as non-incentive in this application. They contain only a resistive bridge without any capacitance or inductance.

1. Set the setting for **SPAN**:
 - a. Identify the output range of the transducer (e.g. -5 to 100 psi).
 - Calculate the range (e.g. 100 psi -5 psi = 105 psi)
 - b. Determine the desired resolution (e.g. 1 psi, 0.1 psi, 0.01 psi).
 - Do not select a resolution that is outside of the tolerance of the transducer
 - The desired resolution is the **DECIMAL PLACE**
 - c. Calculating $XDCR_{MAXOUTmV}$ (**Note:** Only applicable for mV/V transducers).
 - Identify the maximum output of the transducer (located on label or datasheet)
 - Convert this value to mV (millivolts) if some other unit e.g. 1.5V output = 1500mV; 10V = 10000mV
 - d. Utilizing the information from steps a through c, use the following equations (Table 4.6.1) to calculate **SPAN**:

SETTING	DESCRIPTION	
SPAN	XDCR Type	SPAN Calculation
	BK 422	$Span = (RANGE_{xocr}) \cdot 10^{DECIMAL\ PLACE}$
	mV/V	$Span = (XDCR_{MAXOUTmV} / 156.25mV) \cdot (RANGE_{xocr}) \cdot 10^{DECIMAL\ PLACE}$
	Ratio	$Span = (RANGE_{xocr}) \cdot 10^{DECIMAL\ PLACE}$
	1-5V	$Span = (RANGE_{xocr}) \cdot 10^{DECIMAL\ PLACE}$
	4-20mA	$Span = (RANGE_{xocr}) \cdot 10^{DECIMAL\ PLACE}$

Table 4.6.1 • SPAN equations

2. Set the setting for **DECIMAL PLACE**:
 - a. Use the **DECIMAL PLACE** determined in **SPAN** settings, step 2.b.
3. Set the setting for **ZERO**:
 - a. Remove any input to the transducer so that it is at 'rest' (where you would expect a '0' reading).
 - b. Adjust **ZERO** up or down so that the transducer reads as close to '0' as possible.

If necessary make these fine adjustments:

- Transducers are not perfect and there will be differences in the output of an actual transducer and its ideal type. The output will vary between identical transducers of the same model.
- Depending on the precision required by the process, the user can adjust the calculated **SPAN** setting manually to compensate for the error in the actual transducer being used.
- **ZERO** may have to be readjusted after changing **SPAN**.

4.7 USB Drive Port Functions

4.7.1 Downloading Data Logs

The system is easily able to save its data logs to a USB Flash Drive. The data logs will be saved in a folder that is named the same as the Site Name alias in a *.csv file named with the date and time. The USB Flash Drive must be formatted to FAT formatting. Perform the following sequences to save the system data logs:

1. Insert the USB Flash Drive into the USB DRIVE port on the back of the board.
2. CIMARRON USB SERVICE will appear on the display followed by a progress bar and a page count.
3. Wait for the data log save process to complete.
4. Remove the USB Flash Drive when prompted to by the display.

4.7.2 Loading & Saving Settings

The system is easily able to save its System and Application settings to a USB Flash Drive in order for them to be transferred to other system. The USB Flash Drive must be formatted to FAT formatting. Perform the following sequences to save or load the system settings:

1. Stop the system application by pressing the **STOP** button.
2. Press and hold the **BOOT** button.
3. Insert the USB Flash Drive into the USB DRIVE port on the back of the board.
4. Continue to hold down the **BOOT** button until **SETTINGS TRANSFER** appears on the display.
5. Select **LOAD SETTING** or **SAVE SETTINGS**.
6. When the selected action is complete the system will prompt the user to remove the USB Flash Drive and then automatically restart.

5 Troubleshooting

PROBLEM	SOLUTION
System will not exit Permissive open alarm state	Verify Permissive input is closed circuit or jumped short.
System will not ignite	<ul style="list-style-type: none"> • Verify the address is set to DIP switch position 1 on the BMS Module. • Verify power and communication to the ignition module. • Verify proper spark gap and ignition cable and grounding connections. • Inspect MODULE PORT fuse on the ARControl main board. Replace if required.
System will not detect flame	<ul style="list-style-type: none"> • Verify proper placement of the ignition rod spark gap in the pilot flame. • Verify proper ignition cable installation and ground continuity.
System is in low battery mode too often	<ul style="list-style-type: none"> • Verify the solar panel is positioned facing southward without any obstructions from the Sun. • Verify the battery and solar panel are sized properly to handle the system power requirements. • Verify the gauge of wire used for the battery and solar panel are sized properly to handle the system power requirements.
Pilot Status, Independent Process Valve, Process 1 Valve, Process 2 Valve, Process 3 Valve, and Pilot Valve are not outputting power.	Inspect the POWER PORT fuse on the ARControl main board. Replace if required.

6 Maintenance & Service

⚠ WARNING!

Failure to comply with the following safety warning(s) may result in serious personal injury or death.

Do not service the unit in a hazardous area

SPARE PARTS LIST	
PART NUMBER	DESCRIPTION
3181-002	ARControl 2 Amp Spare Fuse
1870-511	BMS Module - Black Ignition Module Puck
1960-170	BMS Module in Class I Division 1 Explosion Proof Enclosure
1960-171	BMS Module on DIN Rail Mounting Bracket
1960-160	5 Watt Solar Panel & 12 Volt 12 Amp Hour SLA Battery with Mounting Brackets
2130-012	12 Volt 12 Amp Hour SLA Battery
148197	12" Dual Probe Thermocouple - Type K for use with BMS Module
8100-020	0-5 psi millivolt pressure transducer with 1/4"-18 NPT male fitting. Class I Division 2 when used with the ARControl BMS

Contact Cimarron Energy, Inc. for information in regard to maintenance, parts, or service at 1-844-746-1676 or visit www.cimarronenergy.com

7 Equipment Ratings


PARAMETER	MINIMUM	TYPICAL	MAXIMUM	UNITS
Ambient Temperature	-40		60	°C
Relative Humidity (Non-Condensing)			100	%
Enclosure Rating		NEMA 4X		
Operating Voltage		12 or 24		VDC
Operating Current	0.015		4	A
Solar Voltage		12 or 24		VDC
Solar Voltage			2	A
ALARM Output Voltage In	3		50	A
ALARM Output Current In			50	mA
All Valves Voltage Output		12 or 24		VDC
All Valves Current Output (Combined)			2	A
Thermocouple 1, 2, & TC BMS		K		
Permissive, Proof of Closure, PS2, & PS1 Input Voltage		5	30	VDC
BMS Module Valve Output Voltage		12 or 24		VDC
BMS Module Valve Output Current			2	A

8 Approvals


- Class I, Division 2, Groups C and D, T4A, Tamb. -40°C to +60°C, Type 4X
- CAN/CSA-C22.2 NO. 61010-1:2012
- CAN/CSA C22.2 NO. 213:2015
- ANSI/ISA 12.12.01: 2015
- UL 61010-1 (3rd Edition)
- ANSI/ISA-61010-1
- CAN/CSA-C22.2
- UL 50E (Ed. 2)

9 Unit Dimensions

9.1 ARControl Enclosure




9.2 BMS CID1 Enclosure



10 BMS CID1 Enclosure Conduit Seal Placement

- A seal shall be installed within 50mm of the enclosure.
- Only approved certified cable gland and conduit sealing fitting shall be used.
- All unused device openings must be fitted with a certified close-up plug.



This Page Intentionally Left Blank

This Page Intentionally Left Blank

